

For use with:

- Chevy small block
- Short water pump
- GM 60 to 80 amp alternator
 - 1. Use Loctite® removable threadlocker 242 (blue) on all fasteners.
 - Bolt alternator bracket [A] to drivers side head using bolt [F] 3/8-16 x 3-1/4" SHCS and [G] 3/8-16 x 1-1/4" SHCS. Tighten.
 - 3. Bolt alternator to bracket [A] using bolt [I[3/8-16 x 3" SHCS. Be sure to position alternator pivot bracket [C] between back of alternator and rear ear of alternator bracket. Shim if necessary at front of alternator boss for proper fit. Do not fully tighten.
 - 4. Bolt pivot bracket threaded bushing [D] to alternator pivot bracket [C] using bolt [J] 1/4-20 x 3/4" FHCS. Tighten.
 - 5. Bolt alternator adjustment arm [B] to alternator using bolt [L] 5/16-18 x 1" BHCS and [V] 5/16" flat washer; and to threaded bushing using bolt [K] ¼-20 x ¾" FHCS. Tighten.
 - Bolt alternator adjustment arm [B] to lower ear on bracket [A] using bolt [M] 3/8-16 x 2-1/2" SHCS and load washer [W]. Do not fully tighten.
 - Install alternator belt on rear groove when using 2-groove pulleys.
 - 8. Put tension on alternator belt and tighten bolts [I] $3/8-16 \times 3''$ SHCS and [M] $3/8-16 \times 2-1/2''$ SHCS.
 - * Shims provided to shim alternator to bracket for a tight fit. Alternator mounting boss may vary due to polishing or plating.

BILL OF MATERIALS			
ITEM	QTY.	DESCRIPTION	SIZE
А	1	Alternator Main Mounting Bracket	
В	1	Alternator Bracket Adjustment Arm	
С	1	Alternator Pivot Bracket	
D	1	Adjustment Arm To Pivot Bracket Threaded Bushing	
F	1	3/8"-16 Socket Head Cap Screw	3-1/4"
G	1	3/8"-16 Socket Head Cap Screw	1-1/4"
I	1	3/8"-16 Socket Head Cap Screw	3"
J	1	1/4"-20 Flat Head Cap Screw	3/4"
K	1	1/4"-20 Flat Head Cap Screw	3/4"
L	1	5/16"-18 Button Head Cap Screw	1"
М	1	3/8"-16 Socket Head Cap Screw	2-1/2"
V	1	Stainless Flat Washer	11/16" x 3/16"
W	1	Stainless Load Washer	3/4" x 3-16"
Х	3	Stainless Flat Washer	3/4" x .060"
**	2	Stainless Flat Washer	3/4" x .032"
**	2	Stainless Flat Washer	3/4" x .010"