



LOWER CONTROL ARM INSTALLATION

Part #'s BCA001, MTCA001, MTCA002, MTCA003, TCA001, TCA002, XCA001, TCA004

NOTE: When performing this installation it is recommended to do one side at a time. Removing both lower control arms at the same time allows the rear to move forward making re-installation more difficult.

Installation:

1. Raise vehicle high enough so that both rear wheels are off the ground and support the vehicle under the frame. **NOTE: Do not support under the axle.**
2. Using 18mm wrenches, remove the control arm bolts from one side then remove the control arm.
3. If using an adjustable version of the control arms, adjust the arms to the factory length using the OE control arms as a guide. Once properly adjusted, apply Loctite blue to the threads and tighten the jam-nuts. If a custom length is desired, the control arms may be adjusted after the installation however an alignment is recommended to confirm side-to-side consistency.
4. If using polyurethane bushings, lube the external bushing surfaces of the new control arms.
5. If using rod-end equipped control arms install the control arms and tighten the bolts to 75 ft. /lbs.
6. If using polyurethane equipped control arms leave the bolts loose until the vehicles' weight is resting on the control arms. With the rear end supporting the vehicles weight, tighten the mounting bolts to 75 ft/lbs. **NOTE:** tightening the control arm bolts with the rear end hanging results in bushing preload and can cause irregular ride height and premature bushing wear.
7. Using a grease gun with a silicone based polyurethane lube, lube each grease fitting with 1-2 pumps. For maximum longevity, re-grease in an additional 500 miles and then every other oil change.

