

Installation Instructions

SHPE0750 Series SaltDogg® Electric Drive Poly Hopper Spreader 0.65 cubic yards Serial Number 2300 and higher.

Table of Contents

General Information	1
Warranty Information.....	1
Safety Precautions	2
Installation Instructions	2-3
Spreader Operation.....	4
Spreader Maintenance	5
Repair Parts & Drawings	6-8

General Information

SHPE0750- spreader with standard length chute
 SHPE0750X- spreader with extended length chute
 Overall Length: 55-1/2 inches
 Overall Width: 48 inches
 Overall Height (installed): 28 inches
 SHPE Empty Weight: 205 lbs
 SHPEX Empty Weight: 214 lbs
 Capacity Struck: .65 cu. yd.

Vehicle Requirements:

½ ton pick-up truck or utility vehicle with 500 lbs. capacity minimum.



WARNING

Do not overload vehicle beyond the vehicle's GVWR or GAWR. Check vehicle's load rating certification sticker for maximum vehicle capacity.

Average Material Weights

<u>Materials to use</u>	<u>Weight (pounds per cubic yard)</u>
Fine Salt-Dry	2,250
Coarse Salt-Dry	1,431
Sand/Salt 50/50 Mix-Dry	2,700

Note: To calculate the total spreader weight (including ice control material), add the empty spreader weight plus the ice control material and spreader accessories.

Safety Precautions


⚠ WARNING

Observe the following Safety Precautions before, during and after operating this spreader. By following these precautions and common sense, possible injury to persons and potential damage to this machine may be avoided.

1. Read this entire Owners Manual before operating this spreader.
2. Read all safety decals on the spreader before operating.
3. Check to make sure all safety guards are securely mounted into place before operating this spreader.
4. Verify that all personnel are clear of the spreader spray area before starting or operating this spreader.
5. Do not overload your vehicle beyond payload limits. If there are any questions, contact the vehicle manufacturer.
6. Do not adjust, clean, lubricate or unclog material jams without first turning off the spreader.
7. Do not climb on or in the spreader during operation.
8. Do not ride on the spreader while the vehicle is in motion.
9. Make sure the spreader is securely fastened to the vehicle in accordance with this manual.
10. Do not operate a spreader that is in need of maintenance or repairs.
11. Always disconnect the battery before removing or replacing electrical components.


Installation Instructions

1. Mounting the Spreader onto the Vehicle
 - A. Remove the tailgate from the vehicle.
 - B. Check the truck bed for any sharp debris or foreign objects. These can cut and seriously damage poly hopper.




- C. Lift spreader using tie downs. See (Fig. 1)
- D. Slide spreader forward in truck bed until the steps on rear legs of the spreader make contact with truck's bed. Measure the distance from the front of the truck bed to front of the hopper's front legs. Fabricate spacer to fit between front of the spreader and front of the bed per Fig. 2.
- E. Center the spreader from side to side on the vehicle. Securely strap the spreader to the truck using four ratchet straps as shown. (Fig. 3) Front straps must be attached to anchor points located in front of the spreader to create longitudinal stability for the spreader. Rear straps must be tightened evenly to secure the spreader in the middle of the truck. Criss-cross straps can be used.

Fig. 2



Verify with the vehicle's manufacturer that the factory installed anchor points are designed for tie-down of such load. Inspect straps and hardware after each time spreader is loaded. Tighten straps and hardware if necessary.

Fig. 3



2. Mounting the Spinner/Chute Assembly

- A. Attach the Chute Assembly to the spreader, by hooking the chute to the spreader by openings in the chute handle.




Fig. 4

- B. Rotate the Chute into operating position and lock using two spring latches.




Fig. 5

3. Install Control Box and Vehicle Wiring Harness (See Fig. 6). **NOTE: THIS IS A WIRE GROUND ELECTRICAL SYSTEM! NO CONNECTIONS TO TRUCK'S FRAME OR BODY ALLOWED!**

Always disconnect battery before attempting to install electrical components on your vehicle.

WARNING

Do not drill holes into fuel tanks, fuel lines, through electrical wiring, etc that may be damaged by drilling.

To insure good performance of your spreader, check the condition of truck's electrical system. Using digital voltmeter, check alternator and battery voltage. The voltage reading should fall between 13.6 and 15.3 volts with engine running, head lights and heater fan turned on. If voltage reading falls out of this range, check and adjust your electric system.

WARNING

Use extreme caution when working around an operating vehicle engine.

- A. Lay out a wiring path for the Vehicle Wiring Harness. Connect the Wire Harness smaller terminal to the Chute's harness, large terminal to the Hopper's harness. Drill all necessary holes or use existing ones to pass the round connector into the trucks cab. Secure harness to truck's frame.
- B. Mount the Controller in a convenient location in the truck cab. Do not mount controller directly in front of the heat vents. Allow ample air space around controller. Protect controller from water, dirt and dust.

CAUTION

DO NOT MOUNT CONTROLLER IN WAY OF AIR BAG DEPLOYMENT


- C. Apply dielectric grease or similar compound to connectors before assembly. Connect the round connector on the wire harness to the round connector on the controller.
- D. Lay out path for the power cable in the truck's engine compartment. Drill hole in the firewall or use an existing one to pass the wire harness. Passing the power cable from inside of the cab to the battery is recommended to protect the large high amperage connector. Do not route the power cable close to exhaust system!
- E. Connect power cable connector to controller.
- F. Connect the power cable ring terminals to the truck battery, white-positive, and black-negative.

ATTENTION

Do not connect black (negative) wire to any part of vehicles frame. Connect this terminal to battery's negative terminal.

- G. Make sure that the Controller is OFF. Connect the small female terminal on the blue wire to the controller Ignition (single red) wire. Connect the blue wire to an accessory wire, terminal or fuse that is controlled by the vehicle's ignition switch located in the fuse panel inside the truck cab. **Do not connect blue wire to high amperage fuse or terminal.**
- H. Attach utility light kit (optional) to spreader hopper in desired location. Connect as shown in Fig. 6. Use utility light kit part number 3018009.

Fig. 6



Spreader Operation

1. Different materials absorb moisture at different rates and some materials may not perform as desired. Substitution of an alternative material may be necessary for optimum performance.
2. When filling hopper use the supplied screen to prevent large chunks of material and debris in the material to get into hopper and cause damage.
3. Material must never be left in hopper for an extended period of time. Material will absorb moisture, bind, harden and could prevent spreader from proper operation or may damage the spreader.
4. The SHPE0750 spreader is equipped with a dual independent speed controller with warning indicators and a vibrator switch. To start the spreader, press the ON-OFF switch. Switch will illuminate. The auger will accelerate to full speed for 2 seconds, then slow down to dialed speed. The spinner will accelerate to full speed for 2 seconds, then slow down to dialed speed.
5. To activate the vibrator press the vibrator switch ON. Vibrator switch will illuminate.
6. To stop the spreader, push ON-OFF switch to OFF position.

Controller Warnings

Check controller instruction sheet for latest controller updates and troubleshooting codes. Controller instruction sheet is inside controller shipping box.

IMPORTANT! INSTALLER, DO NOT DISCARD CONTROLLER INSTRUCTION SHEET. STAPLE SHEET TO SPREADER MANUAL AND GIVE TO END USER!

Note: To unclog auger manually, first remove the chute. Apply 1¼" open wrench on auger's nut. Turn auger counterclockwise several times.

Note: Do not run the vibrator longer than 30 minutes with 15 minutes between runs to avoid overheating.

Spreader Maintenance



WARNING

Always disconnect power when servicing spreader.

1. Wash spreader after every use. Make sure no material is left under auger and/or inside trough.
2. Inspect and retighten fasteners after every 5-7 hours of operation.
3. Lubricate bearing every 7-10 hours of operation using general automotive grease.
4. Inspect terminals/connectors every time you disconnect spreader from wire harness. Apply thin layer of dielectric grease on terminals. If any tarnish/corrosion is found, clean terminals and apply dielectric grease.
5. Use dielectric grease on all electrical connectors before an electrical connection is made or after connector is disconnected
6. Grease and spray with lubricant Auger bearing after every 20 hours of use.
7. Empty the spreader of all ice control materials when not in use. Wash out the spreader to prevent material builds up.
8. It is recommended to cover spreader with the tarp during storage periods. Tarp can be attached to anchors on both sides of tie downs.


End of Season Maintenance

1. Wash spreader. Make sure no material or residue is left in and outside the hopper.
2. Lubricate bearing using general automotive grease.
3. Inspect wire harness, connectors for broken insulation, missing components. Replace if necessary.
4. Apply dielectric grease on all electrical connectors.
5. Store hopper indoors, in a dry, cool place.
6. Remove controller from truck. Store controller indoors, in a dry, cool place.

Summer Storage

1. Apply dielectric grease or similar protective compound on all electrical connectors & protect them with caps before storage.
2. Disconnect and remove speed controller from vehicle and store it in dry and cool place. Protect controller from excessive heat and moisture.
3. Clean hopper and trough from all kinds of debris.
4. Remove, thoroughly lubricate and reinstall trough bearing.
5. Protect hopper from excessive temperatures during summer storage.


Repair Parts-Chute Assembly



Bill of Materials

ITEM	PART NO.	QTY.	DESCRIPTION
1	3007329	1	Chute Poly Std. Length
1	3007526	1	Chute Poly Ext. Length
2	3006833	1	Gear Motor 12 VDC Spinner
3	3007824	1	Retainer Gearmotor
4	-	3	Washer, 5/16 Lock SST
5	3007564	1	Bracket, Shield SST
6	-	3	Screw, Hex HD Cap 5/16 - 18 x 1-1/4 SST
7	3004611	1	Spinner, 12" Poly
8	3007299	1	Handle, Chute
9	3007004	1	Shield, Spinner
10	3007413	1	Cover, Gear Motor, Chute
11	3006753	1	Wire Harness, Chute
12	-	16	Washer, Flat 3/8 USS SST
13	-	10	Screw, HHC 3/8 - 16 x 1 304 SST
14	-	10	Nut, Nylock 3/8 - 16 x 7/16 SST
15	-	6	Screw, Sheet Mtl #12 x 3/4 Hex Washer HD SST
16	-	1	Pin, Clevis, 5/16 x 2-1/2, .141 Hole ZN
17	-	1	Cotter Pin, 1/8 x 1, Zinc
18	3002631	1	Label, "No Step"
19	3007844	1	Decal, "Danger, Stay Clear"


Repair Parts-Trough Assembly



Bill of Materials

ITEM	PART NO.	QTY.	DESCRIPTION
1	3007357	1	Trough Weldment, SHPE
2	3007000	1	Gasket, Felt Bearing
3	3018919	1	Bearing, 2-Hole Flanged 1"
4	-	4	Nut, Nylock 3/8-16 x 7/16 SST
5	3018007	1	Auger
6	3007730	1	Bracket, Vibrator Short
7	3007416	1	Vibrator 200lbs. 12 VDC
8	3007824	1	Retainer Gear Motor, Chute
9	3009995	1	Gear Motor, Auger SHPE
10	-	3	Washer, 5/16-18 x 5/8 SST Lock
11	-	3	Screw, HHC 5/16-18 x 5/8 SST
12	-	1	Pin, Clevis, 5/16 x 1 1/2, w/ 5/32 PH, ZN
13	-	1	Cotter Pin, 1/8 x 1, Zinc
14	3006844	1	Wire Harness
15	3019085	1	Motor Replacement for 3009995

Repair Parts-Hopper Assembly




Bill of Materials

ITEM	PART NO.	QTY.	DESCRIPTION
1	3011360	1	Hopper, Poly .6 cu. yds.
2	3011865	1	Trough Assembly, SHPE
3	—	10	Washer, Flat 3/8 x 1.5 x 0.48 SST
4	—	10	Washer, Lock RHS 3/8 SST
5	—	10	Screw, HHC 3/8-16 x 3/4 SST
6	3007731	1	Bracket Vibrator, Long SST
7	—	2	Nut, Nylock 3/8-16 x 7/16 SST
8	3007821	1	Strain Relief Bushing
9	3007236	1	Cover, Gear Motor

ITEM	PART NO.	QTY.	DESCRIPTION
10	—	6	Washer, 1/4" Spring Lock SST
11	—	6	Screw, Hex HD Cap 1/4-20.5 SST
12	—	4	Screw, Sheet MTL #12 x 1.0 Hex Washer HD SST
13	4375	2	Clamp, Hose .4375, 9/32 Hole
14	—	8	Nut, Nylock 1/2-13 ZN
15	3009802	8	Anchor, Tarp, Poly SHPE
16	3006974	4	Stud, 1/2-13x.75 Both Ends, 9.75" LG, ZN
17	3006958	4	Tie Down

Repair Parts - Spreader Assembly



Bill of Materials

ITEM	PART NO.	QTY.	DESCRIPTION
1	3011878	1	Hopper Assembly, SHPE0750
2	3007412	1	Standard Chute, Poly SHPE1500
2	3007527	1	Extended Chute, Poly SHPE1500
3	3011382	1	Plate, Serial No. SHPE0750 Series
4	-	2	Screw, Sheet Mtl #12X1.0 Hex Washer HD SST
5	9240132	1	Decal #2, Danger Before SVCE
6	3011727	1	Screen, Flat SHPE0750
7	3008787	4	Retainer, Screen
8	-	4	Washer, Lock RHS-3/8 SST
9	-	4	Screw, HHC 3/8-16 X 1 304 SST

ITEM	PART NO.	QTY.	DESCRIPTION
10	3012898	1	Decal, Check Straps
11	3021239	1	Hardware Kit
12	3014199	1	Controller, SHPE, SaltDogg
13	3006724	1	Wire Harness, Main
14	3006842	1	Power Cable, Control Box
15	1496505	1	Hold Down Kit, Spreader (4 Straps)
16	3011370	1	Tarp SHPE0750
17	0203700	1	Wire Assembly, 36" Long
18	9225	8	S-Hook, 2.5" ZW, Tarp Strap
19	TS20	4	Strap, Rubber Tarp 20", (27" Max)