

## 13215 INSTALLATION INSTRUCTIONS



Safety glasses should be worn at all times while installing this product.

YEARS: 2015-PRESENT

MAKE: RAM

**MODEL: PROMASTER CITY** 

STYLE: VAN


**///** WARNING: NEVER EXCEED YOUR VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY

**WEIGHT CARRYING:** 

TRAILER WEIGHT: 3500 LBS. TONGUE WEIGHT: 350 LBS.

PRO INSTALL TIME: **60 MIN.**NOVICE INSTALL TIME: **120 MIN.** 


IF YOU ARE HESITANT TO UNDERTAKE
THIS TASK ON YOUR OWN, CONTACT AN AUTHORIZED
CURT INSTALLER FOR ADDITIONAL ASSISTANCE.



#### **INSTALLATION TIPS:**

- 1. BEFORE YOU BEGIN INSTALLATION, READ ALL INSTRUCTIONS THOROUGHLY.
- 2. TO EASE INSTALLATION, 2 PEOPLE MAY BE REQUIRED.
- 3. USING PROPER TOOLS WILL GREATLY IMPROVE THE QUALITY OF THE INSTALL AND REDUCE THE TIME REQUIRED.


#### LEVEL OF DIFFICULTY: MODERATE



**VEHICLE PHOTO:** 




### HITCH ILLUSTRATION:



MAKE SURE YOUR HITCH MATCHES

#### **INSTALLATION WALKTHROUGH:**



1. Remove (3) bottom bumper cover fasteners with a T27 socket and (10) wheel well fasteners with a phillips screwdriver.





2. Remove (2) fasteners located at the top of the bumper cover hidden behind the wheel well with a T27 socket.



#### **INSTALLATION WALKTHROUGH:**

3. Remove (4) top bumper cover and (6) taillight fasteners with a T27 socket.






4. Remove (2) final bumper cover fasteners below the taillight assembly with a T27 socket. Gently pull the sides of the bumper cover away from the vehicle until the cover is detached.





5. Disconnect the harness at the bumper. Then, place the bumper cover aside. Remove (6) bolts for the bumper with a 15mm socket, and set the bumper aside.







### **INSTALLATION WALKTHROUGH:**

6. Raise the hitch into position, and reinstall the bumper over the hitch. Loosely install the factory bolts.



7. Torque all M10 fasteners to 45 ft-lb.

Reinstall the bumper cover, harness, and taillights in reverse order.





#### TOWING SAFETY INFORMATION


#### Gross Trailer Weight / GTW

The Gross Trailer Weight is the weight of the trailer & cargo. Measure this by putting the fully loaded trailer on a vehicle scale.



#### Tongue Weight / TW

The downward force that is exerted on the hitch ball by the coupler. The tongue weight will vary depending on where the load is positioned in relationship to the trailer axie(s). To measure the tongue weight, use either a commercial scale or a bathroom scale with the coupler at towing height. When using a bathroom scale with heavier tongue weights, use the method shown and multiply the scale reading by 3.



#### Weight Carrying / WC

The total weight of both the trailer and the cargo inside. Never exceed the weight capacity of your trailer hitch.

#### Weight Distribution / WD


Used to balance the weight of the cargo between the front and rear wheels throughout the trailer, allowing for better steering, braking, and level riding.



#### Sway Control

A device used to reduce the lateral movements of the trailer that are caused by the wind. This works in conjunction with a weight distribution hitch. Do not use this on a class 1 or 2 hitch, or with surge brakes.


### How Much Can You Safely Tow?



#### Ball Mount

The ball mount is placed inside the opening of the receiver hitch which is mounted to the vehicle. Make sure a hitch pin and clip is properly securing the ball mount to the receiver hitch before you begin towing.

A: Rise. B: Drop. C: Hole Size. D: Length.



#### Trailer Ball

The connection from the hitch to the trailer. There are many factors that determine the correct hitch ball:

- Number one is the hitch ball's gross trailer weight rating.
- The mounting platform must be at least 3/8" thick.
- The hole diameter must not be more than 1/16" larger. than the threaded shank.
- Every time you tow, check the nut and lock washer to make sure they are fastened securely.

  A: Ball Dia. B: Shank Length, C: Shank Dia. D: Shank Rise.



#### Coupler

The component that is placed over the trailer ball to connect the vehicle to the trailer. Be sure that the coupler size matches the size of the hitch ball and that the coupler handle is securely fastened. To determine what size hitch ball you need for your application you will need to know the size of coupler that is on the trailer. Be sure your coupler is properly adjusted to the ball you are using.

NOTE: For added security the use of safety devices such as Coupler Safety Pins and Locks is strongly recommended.

#### Safety Chains

Safety chains are a requirement and should be crossed under the tongue of the trailer so that: the tongue will not drop to the road if it becomes separated from the hitch. Always leave enough slack so you can turn. Never allow the safety chains to drag on the ground and never attach the chains to the bumper.

Trailer Classification: Safety Chain Breaking Force - Minimum

Class 1: 2,000 lbs. (8.9 kN) Class 2: 3,500 lbs. (15.6 kN) Class 3: 5,000 lbs. (22,2 kN)

The strength rating of each length of safety chain or its equivalent and its attachments shall be equal to or exceed in minimum breaking force the GVWR (Gross Vehicle Weight Rating) of the trailer.

#### Electrical

Trailer lights, Electric Brakes, Break-away systems - Every time you tow, be sure to check that all components are working properly.

Wiring identification by color:



CURT DISCLAIMER: WIRING COLOR SHOWN WORK IN CONJUNCTION WITH CURT MANUFACTURING PRODUCTS.


# **RAM PROMASTER CITY**

GROSS LOAD CAPACITY WHEN USED AS A WEIGHT CARRYING HITCH: 3500 LBS. TRAILER WEIGHT & 350 LBS. TONGUE WEIGHT.

\*\*\*DO NOT EXCEED VEHICLE MANUFACTURER'S RECOMMENDED TOWING CAPACITY.\*\*\*

WARNING: ALL NON-TRAILER LOADS APPLIED TO THIS PRODUCT MUST BE SUPPORTED BY 18050 STABILIZING STRAPS.

\*\* FAILURE TO PROPERLY SUPPORT NON-TRAILER LOADS WILL VOID PRODUCT WARRANTY\*\*



## **INSTALLATION STEPS**

- 1. Remove (3) bottom bumper cover fasteners with a T27 socket and (10) wheel well fasteners with a phillips screwdriver.
- 2. Remove (2) fasteners located at the top of the bumper cover hidden behind the wheel well with a T27 socket.
- 3. Remove (4) top bumper cover and (6) taillight fasteners with a T27 socket.
- 4. Remove (2) final bumper cover fasteners below the taillight assembly with a T27 socket. Gently pull the sides of the bumper cover away from the vehicle until the cover is detached.
- 5. Disconnect the harness at the bumper. Then, place the bumper cover aside. Remove the (6) bolts attaching the bumper with a 15mm socket, and set the bumper aside.
- 6. Raise the hitch into position, and reinstall the bumper over the hitch. Loosely install the factory bolts.
- 7. Torque all M10 fasteners to 45 ft-lb. Reinstall the bumper cover, harness and taillights in reverse order.

PERIODICALLY CHECK THIS RECEIVER HITCH TO ENSURE THAT ALL FASTENERS ARE TIGHT AND THAT ALL STRUCTURAL COMPONENTS ARE SOUND.

Learn more about trailer hitches and towing we have.