

ATTENTION: Refer to the appropriate shop manual for your vehicle to obtain specific service procedures for this part. If you do not have a service manual or lack the skill to install this part, it is recommended that you seek the services of a qualified technician. Pay special attention to all cautions and warnings included in the shop manual. Read and follow all instructions carefully.

**REMOVAL/INSTALL OF DOOR LOCK ACTUATOR (746-015)
2006–00 Suburban 1500/2500, Yukon XL 1500/2500, 2006–01 Tahoe/Yukon,
2006–02 Escalade, 2000 Tahoe, Yukon w/o 5.7 engine**


General Tech Tips:

- Use painter's tape rather than duct tape to secure window. It will not damage paint or leave sticky residue.
- A plastic pry tool is useful. It will not easily damage delicate trim like a screwdriver or metal pry bar.

**PLEASE WEAR SAFETY
GLASSES!**

**Tools required for removal
and installation of door lock actuator:**

- **Phillips head screwdriver**
- **T-15 Torx bit**
- **10mm socket and ratchet assembly**
- **Trim panel removal tool**



INSTALL/REMOVAL INSTRUCTIONS: DOOR LOCK ACTUATOR

ATTENTION: Refer to the appropriate shop manual for your vehicle to obtain specific service procedures for this part. If you do not have a service manual or lack the skill to install this part, it is recommended that you seek the services of a qualified technician. Pay special attention to all cautions and warnings included in the shop manual. Read and follow all instructions carefully.

TECH NOTE: The part you are about to install varies in appearance from what you are removing. This does not affect the fit or function of the part.

ORIGINAL OE:



OE SUPERSESSION:



DORMAN REPLACEMENT:



INSTALL/REMOVAL INSTRUCTIONS: DOOR LOCK ACTUATOR


ATTENTION: Refer to the appropriate shop manual for your vehicle to obtain specific service procedures for this part. If you do not have a service manual or lack the skill to install this part, it is recommended that you seek the services of a qualified technician. Pay special attention to all cautions and warnings included in the shop manual. Read and follow all instructions carefully.

Removal Instructions

STEP 1: Using a Phillips head screwdriver, remove the lift gate pull down strap assembly.






STEP 2: Using a trim panel removal tool, remove the upper portion of the interior lift gate panel assembly. Once the upper portion of the interior trim panel has been removed, disconnect the lower portion of the interior trim panel.



INSTALL/REMOVAL INSTRUCTIONS: DOOR LOCK ACTUATOR

ATTENTION: Refer to the appropriate shop manual for your vehicle to obtain specific service procedures for this part. If you do not have a service manual or lack the skill to install this part, it is recommended that you seek the services of a qualified technician. Pay special attention to all cautions and warnings included in the shop manual. Read and follow all instructions carefully.



STEP 3: Disconnect the electrical connectors.



INSTALL/REMOVAL INSTRUCTIONS: DOOR LOCK ACTUATOR

ATTENTION: Refer to the appropriate shop manual for your vehicle to obtain specific service procedures for this part. If you do not have a service manual or lack the skill to install this part, it is recommended that you seek the services of a qualified technician. Pay special attention to all cautions and warnings included in the shop manual. Read and follow all instructions carefully.


STEP 4: Using a 10mm socket and ratchet assembly, remove the three (3) lift gate latch bracket retaining screws.




INSTALL/REMOVAL INSTRUCTIONS: DOOR LOCK ACTUATOR

ATTENTION: Refer to the appropriate shop manual for your vehicle to obtain specific service procedures for this part. If you do not have a service manual or lack the skill to install this part, it is recommended that you seek the services of a qualified technician. Pay special attention to all cautions and warnings included in the shop manual. Read and follow all instructions carefully.

STEP 5: In an upward motion, raise the lift gate latch retaining bracket. Once you have the lift gate latch retaining bracket held in position, use a T-15 Torx bit to remove the lift gate latch retaining screw. **NOTE:** The lift gate latch retaining screw is on the back side of the lift gate latch retaining bracket.



STEP 6: Slide the lift gate lock actuator toward the passenger side of the vehicle, to release the actuator from the lift gate latch retaining bracket. Once the actuator is disconnected from the bracket, slide the lift gate actuator arm out of position. **NOTE:** Slide the arm toward the driver's side of the vehicle.




INSTALL/REMOVAL INSTRUCTIONS: DOOR LOCK ACTUATOR


ATTENTION: Refer to the appropriate shop manual for your vehicle to obtain specific service procedures for this part. If you do not have a service manual or lack the skill to install this part, it is recommended that you seek the services of a qualified technician. Pay special attention to all cautions and warnings included in the shop manual. Read and follow all instructions carefully.

Installation Instructions

STEP 1: Slide the lift gate actuator arm into the lift gate latch bracket assembly.




STEP 2: Attach the lift gate lock actuator into position.





INSTALL/REMOVAL INSTRUCTIONS: DOOR LOCK ACTUATOR

ATTENTION: Refer to the appropriate shop manual for your vehicle to obtain specific service procedures for this part. If you do not have a service manual or lack the skill to install this part, it is recommended that you seek the services of a qualified technician. Pay special attention to all cautions and warnings included in the shop manual. Read and follow all instructions carefully.

STEP 3: Using a T-15 Torx bit, install the lift gate lock actuator retaining screw on the back side of the lift gate latch bracket.




STEP 4: Using a 10mm socket and ratchet assembly, install the three (3) lift gate latch bracket retaining screws.



INSTALL/REMOVAL INSTRUCTIONS: DOOR LOCK ACTUATOR

ATTENTION: Refer to the appropriate shop manual for your vehicle to obtain specific service procedures for this part. If you do not have a service manual or lack the skill to install this part, it is recommended that you seek the services of a qualified technician. Pay special attention to all cautions and warnings included in the shop manual. Read and follow all instructions carefully.

STEP 5: Attach the electrical connectors.



STEP 6: Install the lower portion of the lift gate interior trim panel. Once the lower portion has been installed, install the upper portion of the interior trim panel.

NOTE: Be sure to align the interior trim panel retainers with their corresponding holes. Failure to do so will cause damage to the retainers.



INSTALL/REMOVAL INSTRUCTIONS: DOOR LOCK ACTUATOR

ATTENTION: Refer to the appropriate shop manual for your vehicle to obtain specific service procedures for this part. If you do not have a service manual or lack the skill to install this part, it is recommended that you seek the services of a qualified technician. Pay special attention to all cautions and warnings included in the shop manual. Read and follow all instructions carefully.

STEP 7: Using a Phillips head screwdriver, install the interior lift gate pull handle retaining screw.



STEP 8: Verify that the lift gate lock actuator is operating properly and that the interior trim panel is secure.