

TERMINATOR[™]X

TERMINATOR[™]X MAX

DIRECT INJECTION SYSTEM



QUICK START MANUAL – 199R12082

NOTE: These instructions must be read and fully understood before beginning installation. If this manual is not fully understood, installation should not be attempted. Failure to follow these instructions, including the pictures may result in subsequent system failure.

TABLE OF CONTENTS:

- 1.0 INTRODUCTION
- 2.0 WARNINGS, NOTES, AND NOTICES
- 3.0 ADDITIONAL ITEMS REQUIRED FOR INSTALLATION
- 4.0 TOOLS REQUIRED FOR INSTALLATION
- 5.0 REMOVAL OF EXISTING COMPONENTS
- 6.0 TERMINATOR X DIRECT INJECTION SYSTEM INSTALLATION
 - 6.1 Fuel Pump, Fuel Line, and Filter Installation
 - 6.2 Oxygen Sensor Installation
 - 6.2.1 Oxygen Sensor Mounting Procedure
 - 6.3 ECU Mounting
- 7.0 WIRING
 - 7.1 Important Wiring “Do’s and Don’ts”
- 8.0 WIRING HARNESS INSTALLATION
 - 8.1 Main Power/Battery Connection
- 9.0 PRIMARY HARNESS INSTALLATION AND SENSOR CONNECTIONS
 - 9.1 ECU Connectors
 - 9.2 Harness Routing
 - 9.3 Sensor Connections & Outputs
 - 9.3.1 Oil Pressure Sensor
 - 9.3.2 Coolant Temperature Sensor (CTS)
 - 9.3.3 Wide Band Oxygen Sensor (WBO2)
 - 9.3.4 Fuel Pressure (Fuel)
 - 9.3.5 Manifold Air Temperature (MAT)
 - 9.3.6 GDI Bulkhead
 - 9.3.7 Knock Sensors
 - 9.3.8 Manifold Absolute Pressure Sensor (MAP)
 - 9.3.9 Throttle Position Sensor (TPS)
 - 9.3.10 Idle Air Control (IAC)
 - 9.3.11 Fuel Injectors
 - 9.3.12 Ignition Coils
 - 9.3.13 Coil Ground Wires
 - 9.3.14 Handheld Connections - (CAN1)
- 10.0 LOOSE WIRES
- 11.0 ADDITIONAL INPUTS & OUTPUTS
- 12.0 TRANSMISSION HARNESS
 - 12.1 GM Transmission Wiring
 - 12.2 Ford Transmission Wiring
- 13.0 DRIVE-BY-WIRE HARNESS
 - 13.1 Overview
 - 13.2 Warnings!
 - 13.3 Installation
 - 13.4 System Safeties
 - 13.5 Throttle Body “Limp Home” Position
 - 13.6 Drive-By-Wire DO’S and DON’TS
 - 13.7 GM DBW Wiring
- 14.0 FINAL ECU CONNECTION
- 15.0 TERMINATOR X™ INSTRUCTIONS AND TUNING
- 16.0 INITIAL POWER-UP
- 17.0 HANDHELD NAVIGATION & USE
 - 17.1 Making Adjustments
- 18.0 HOME SCREEN
- 19.0 CALIBRATION WIZARD
- 20.0 TPS AUTOSSET
- 21.0 SENSOR VERIFICATION
- 22.0 STARTUP
- 23.0 AFTER-STARTUP
- 24.0 IDLE SETTING/CABLE OPERATED THROTTLE PLATE SETTING
- 25.0 SELF-TUNING
- 27.0 DIAGNOSTIC LED’S
 - Terminator X ECU LED Reference Chart
 - GDI LED Reference Chart

1.0 INTRODUCTION

Holley Performance Products has written this manual for the installation of the **TERMINATOR X™ DIRECT INJECTION** fuel injection system. This manual contains the information necessary for the installation of the hardware contained in this kit, which includes the ECU, wiring, and 3.5" touch screen. It also contains basic tuning information. This instruction sheet does not include installation instructions for the fuel system (pump, filters, regulators and lines). Please read all the **WARNINGS** and **NOTES**, as they contain valuable information that can save you time and money. It is our intent to provide the best possible products for our customer; products that perform properly and satisfy your expectations. By using this number, you may obtain any information and/or parts assistance that you may require. Please have the part number of the product you purchased when you call.

2.0 WARNINGS, NOTES, AND NOTICES

NOTE: This system does not contain fuel system components that are required including the fuel pump, fuel filters, fuel pressure regulator, and lines. Holley offers complete kits can be purchased separately (526-1, 526-2, 526-3, & 526-4).

WARNING! The **TERMINATOR X DIRECT INJECTION** systems consist of a number of sophisticated components. Failure of any one component does not constitute, nor does it justify, warranty of the complete system. Individual service items are available for replacement of components. If assistance is required or if you need further warranty clarification, you can call Holley Technical Service at the number shown above.

WARNING! To preserve warranty, these instructions must be read and followed thoroughly and completely before and during installation. It is important that you become familiar with the parts and the installation of the **TERMINATOR X DIRECT INJECTION** system before you begin. Failure to read and understand these instructions could result in damage to **TERMINATOR X DIRECT INJECTION** components that are not covered by the warranty and could result in serious personal injury and property damage.

WARNING! The oxygen sensor in this kit is recommended for use with **ONLY** unleaded fuel. Use of leaded fuels will degrade the oxygen sensor and will result in incorrect exhaust gas oxygen readings and improper fuel delivery. Failure to follow these directions does not constitute the right to a warranty claim.

WARNING! Failure to follow all of the above will result in an improper installation, which may lead to personal injury, including death, and/or property damage. Improper installation and/or use of this or any Holley product will void all warranties.

WARNING! Use of some RTV silicone sealers will destroy the oxygen sensor used with this product. Ensure the RTV silicone sealant you use is compatible with oxygen sensor vehicles. This information should be found on the RTV package.

WARNING! For the safety and protection of you and others, only a trained mechanic having adequate fuel system experience must perform the installation, adjustment, and repair. It is particularly important to remember one of the very basic principles of safety: fuel vapors are heavier than air and tend to collect in low places where an explosive fuel/air mixture may be ignited by any spark or flame resulting in property damage, personal injury, and/or death. Extreme caution must be exercised to prevent spillage and thus eliminate the formation of such fuel vapors.

WARNING! This type of work **MUST** be performed in a well-ventilated area. Do not smoke or have an open flame present near gasoline vapors or an explosion may result.

3.0 ADDITIONAL ITEMS REQUIRED FOR INSTALLATION

- Fuel System
- Return Fuel Lines

A 0-100 psi fuel gauge or pressure transducer is recommended to check for proper fuel pressure. PN 554-102 is a 0-100 PSI pressure sensor that can be purchased as well that will plug into the **TERMINATOR X™** harness to check and monitor fuel pressure. It requires a 1/8" NPT port for installation (Holley fuel pressure regulators have a 1/8" NPT port).

NOTE: Earl's Fuel Injection hose adapters allow for easy installation of a fuel pressure sensor near the fuel rail.

4.0 TOOLS REQUIRED FOR INSTALLATION

- Standard wrench set
- Medium blade screwdriver
- Drill and assorted bit sizes
- Factory Service Manual for your vehicle
- Small blade screwdriver
- #2 Phillips screwdriver
- Hole saw (2") (depending on ECU location)
- O2 Bung Installation (drilling, welding)
- Allen wrench set
- Digital volt meter
- Terminal crimping tool

An assistant is necessary for some installation and adjustment procedures and should be present for safety reasons.

5.0 REMOVAL OF EXISTING COMPONENTS

1. Disconnect the battery.
2. If applicable, remove the existing OEM main wiring harness. Consult the factory service manual for details on how to properly remove the harness.

6.0 TERMINATOR X DIRECT INJECTION SYSTEM INSTALLATION

6.1 Fuel Pump, Fuel Line, and Filter Installation

A complete high pressure EFI fuel system must be installed for the TERMINATOR X™. The pump should be capable of supplying a minimum of 255 liters/hour or 400 lb./hr. of fuel at 43 psi. If using an in-line fuel pump, there should be a coarse pre-filter before the pump. All systems should contain a 10 micron post filter after the fuel pump. An EFI fuel pressure regulator is required. It should be installed after the fuel rail. See **Figure 1** below for proper fuel system plumbing.

Holley offers multiple fuel system kits. These kits contain all components except the return line. Examples of these kits are:

- 526-1 – Braided Stainless Lines, Billet Pump, Regulator, and Filters
- 526-2 – Pro-Lite 350 Hose, Billet Pump, Regulator, and Filters
- 526-3 – Super Stock Hose, Billet Regulator, 12-920 Fuel Pump, and Filter
- 526-4 – Super Stock Hose, Billet Regulator, 12-920 Pump, and Metal Filters




Figure 1

6.2 Oxygen Sensor Installation

The oxygen sensor should be mounted at a point where it can read a good average of all the cylinders on one bank. This would be slightly after all the cylinders merge. Do NOT mount the sensor far back in the exhaust as this will negatively impact closed loop operation response. If you have long tube headers, mount the sensor approximately 1-10" after the collector. You must have no less than 18 – 24" of exhaust pipe after the sensor.

TERMINATOR X™ EFI systems come with a Bosch LSU 4.9 wideband oxygen sensor. Make sure your sensor looks like **Figure 2**.



Figure 2

6.2.1 Oxygen Sensor Mounting Procedure

NOTE: Never run the engine with the oxygen sensor installed if it is not plugged in and powered by the ECU, or it will be damaged. If you need to plug the hole temporarily, use an O₂ sensor plug or a spark plug with an 18mm thread.

NOTE: Someone with experience in welding exhaust systems should install the oxygen sensor boss. Any competent exhaust shop will be able to perform this task at a minimum cost. (Note: If you weld on the car, make sure all wiring to the ECU is disconnected, and its best to remove the ECU from the vehicle when welding).

WARNING! Use of leaded fuel will degrade an oxygen sensor. Prolonged use is not recommended unless periodic replacement is performed.

WARNING! Use of some RTV silicone sealers will destroy the oxygen sensor used with this product. Ensure the RTV silicone sealant you use is compatible with oxygen sensor vehicles. This information should be found on the RTV package.

1. Locate a position for the oxygen sensor as close to the engine as possible. If your vehicle has catalytic converters, the oxygen sensor MUST be located between the engine and the catalytic converters.




Figure 3

NOTE: The oxygen sensor should be mounted in such a way that the condensation in the exhaust tubing will not enter the sensor. Mount the O₂ sensor in the upper half of the exhaust tubing, with the angle "x", shown above, being greater than 10°. **Figure 3** indicates that the sensor can be mounted on either side of the exhaust tubing.

2. Drill a 7/8" hole in the location picked for the sensor. Weld the threaded boss into the 7/8" hole. Weld all the way around the boss to insure a leak proof connection. Install the oxygen sensor into the threaded boss and tighten securely. It is a good idea to add anti-seize to the threads to aid in removal. Do not get any anti-seize on the tip of the sensor.
3. On vehicles equipped with an AIR pump, the oxygen sensor must be mounted before the AIR injection into the exhaust, or the AIR pump must be disconnected. Holley recommends that if the AIR is injected into both exhaust manifolds, mount the oxygen sensor into the pipe immediately after the exhaust manifold. Disconnect the AIR pump tube from the exhaust manifold and plug both ends. Check with local ordinances for the legality of this procedure in your area.

WARNING! Failure to disconnect the AIR pump or locating the oxygen sensor downstream from AIR injection will result in an extremely rich mixture, which could cause drivability problems and severe engine damage.

6.3 ECU Mounting

Both ECUs can be mounted inside the passenger compartment (preferable location) or in the engine compartment. If mounted in the engine compartment, follow these guidelines:

- The ECUs should be located such that they are not being directly hit by water or road debris.
- They should also be located such that they are not extremely close to exhaust manifolds or headers.
- They should be mounted such that they are as far away from spark plug wires, CD ignition boxes, or other "electrically noisy" devices as is reasonably possible.
- Make sure the connector end of the ECUs are pointed DOWN such that water can't make its way into the ECU terminals.

Do not over-tighten mounting hardware if the ECU is not mounted on a flat surface.

7.0 WIRING

This section overviews how to properly install the wiring harnesses for this system.

7.1 Important Wiring “Do’s and Don’ts”

An EFI system depends heavily on being supplied a clean and constant voltage source. The grounds of an electrical system are just as important as the power side.

TERMINATOR X™ ECU’s contain multiple processing devices that require clean power and ground sources. The wiring harnesses for them must be installed in such a manner that they are separated from “dirty” power and ground sources.

DO’S

- Install the main power and ground directly to the battery – *to the POSTS/TERMINALS, not to any other place!*
- Keep sensor wiring away from high voltage or “noisy/dirty” components and wiring, especially secondary ignition wiring (plug wires), ignition boxes and associated wiring. It is best that the plug wires not physically contact any EFI wires.
- Properly crimp or crimp and solder any wire connections. Apply quality heat shrink over any of these connections.
- It is critical that the engine has a proper ground connection to the battery and chassis.

DON'TS

- NEVER run high voltage or “noisy/dirty” wires in parallel (bundle/loom together) with any EFI sensor wiring. If wires need to cross, try to do so at an angle.
- Do not use the electric fan outputs to directly power a fan. They must only trigger a relay.
- Do not use improper crimping tools.
- Don’t use things like “t-taps”, etc. Use proper crimpers/solder and heat shrink.
- It is never recommended to splice/share signal wires (such as TPS, etc.) between different electronic control units (i.e. “piggyback”).
- Do not connect the red/white switched +12V wire to “dirty” sources, such as the ignition coil, audio systems, or 12V sources connected to HID head lamps.

8.0 WIRING HARNESS INSTALLATION

8.1 Main Power/Battery Connection

The TERMINATOR X™ ECU and GDI CONTROLLER both have a main battery power and ground connector on the right side of the ECU. The right position, Terminal “A” is the ground (black wire). The black wire should go to the negative post DIRECTLY on the battery. The left position, Terminal “B” is the positive terminal (red wire). The red wire should go to the positive post DIRECTLY on the battery. If you have a “dual post” battery, it is a great idea to purchase separate posts/studs to connect the ECU powers and grounds to the non-used terminals. Always use the fused power cable with the proper connectors supplied by Holley only. **Don’t connect to the ECUs until after ALL wiring and installation is performed.**



Figure 4

9.0 PRIMARY HARNESS INSTALLATION AND SENSOR CONNECTIONS

These sections review the Main Harness installation and sensor connections that must be completed. The Main Harness is the primary harness that supports all the primary engine sensors, fuel and ignition. There are two main connectors for this harness that plug into the ECU.




Figure 5

9.1 ECU Connectors

TERMINATOR™ X ECU – The TERMINATOR™ X ECU has **two** main connectors:

- **J1A** - The first connector next to the USB connector is the “J1A” connector (34 pin). This connector is primarily an “Input” connector. It contains all the sensor inputs and wide band oxygen sensor control.
- **J1B** - The second connector is the “J1B” connector (26 pin). This connector is the “output” connector. It has 8 injector outputs and outputs for other devices.
- **J3** – Connection point for the Drive-By-Wire harness (X Max Only).
- **J4** – Connection point for the Transmission harness (X Max Only).



Figure 6



Figure 7

9.2 Harness Routing

NOTE: Some kits also include harness specific instructions with more details about harness routing, connectors, etc. Please refer to those instructions for more information.

If the ECU is mounted in the interior, it will have to be routed through the firewall into the engine compartment. Use a 2" hole saw to create a hole in a desired location if no other point of access is available. Use a grommet for a 2" hole to seal this area. Holley recommends Earl's part number 29G001ERL

If the ECU is mounted in the engine compartment, the 3.5" Touch Screen cable will have to be routed to the "CAN" connector on the main harness (located near the ECU connector main connector). This is assuming you want to access the hand-held module after startup. This will require routing the small CAN connector somewhere through the firewall.

Connect the J1A and J1B connectors of the main harness into the ECU.

A 40A Relay is located on the main harness. This powers the injectors and fuel pump. There is also a 20 amp fuse for the injectors and fuel pump pre-installed in this location.

9.3 Sensor Connections & Outputs

The following indicates the primary sensors that are required to be connected. Each connector on the main harness is labeled with the sensor name. The name on this label for each sensor is in parenthesis below.

Note: Some of the connector images shown below may not be the same as the connector on your harness. See the separate harness instructions included with your kit for more information.

9.3.1 Oil Pressure Sensor

[Optional] This connector will connect to some factory Oil Pressure sensors on LT applications, located at the front of the engine. For other applications, utilize the Holley 554-102 0-100 psi transducer.



Figure 8 Oil Pressure

9.3.2 Coolant Temperature Sensor (CTS)

[Required] Connect the CTS connector to the sensor, which should be installed in a coolant passage in either the water pump or cylinder head. Do not install the sensor in the thermostat housing.




Figure 9 CTS

9.3.3 Wide Band Oxygen Sensor (WBO2)

[Required] Connect to the oxygen sensor previously installed. There is an adapter harness included in the kit, which allows the Bosch 4.9 sensor to plug into the main engine harness. If you need an extension cable, one is available from Holley (P/N 534-199). The TERMINATOR X™ systems are intended to be used with a Bosch LSU 4.9 wide band oxygen sensor supplied by Holley. Service part number 554-155.




Figure 10 WBO2



Figure 11 WBO2

9.3.4 Fuel Pressure (Fuel)

[Optional] A fuel pressure transducer connector is pre-installed in the main harness. The system is plug-and-play configured for a Holley 100 PSI pressure transducer (can be purchased under PN 554-102). If these are not connected to a pressure transducer, the Fuel Pressure shown on the hand held display will not be accurate. This will not cause any issues. Connect to the transducer (if installed).



Figure 12 Fuel Pressure

9.3.5 Manifold Air Temperature (MAT)

[Required] Connect to the MAT sensor. Sensor should be placed somewhere in the intake manifold.




Figure 13 MAT

9.3.6 GDI Bulkhead

Connect the GDI connector shown in **Figure 14** to the mating connector on your GDI subharness. The GDI subharness is detailed separately below.



Figure 14 GDI

9.3.7 Knock Sensors

[Not present on all harnesses] Connect to the Knock Sensor(s). Knock Sensors are not enabled in Terminator X base calibrations, but may be configured by using Terminator X software.




Figure 15 Knock

9.3.8 Manifold Absolute Pressure Sensor (MAP)

[Required] For naturally aspirated & nitrous engines, you can connect the internal 1Bar MAP sensor located on the ECU to an available intake manifold port by using the appropriately sized quick-turn adapter.

Other MAP sensors can be used by plugging the MAP sensor connector into the sensor, or using an adapter harness (see part numbers in the note below). The following sensors can be configured using the wizard in the Terminator X handheld:

<u>Naturally Aspirated & Nitrous</u>	<u>Turbo and Supercharger</u>
GM PN 12644228 1bar	GM PN 12644807 3.5bar
Internal 1bar	GM PN 12592525 2.5bar
Holley 1bar (538-24)	Holley 2bar (538-13)
Holley 1bar SS (554-133)	Holley 3bar (554-107)
	Holley 3.5bar SS (554-134)
	Holley 5bar SS (554-108)

MAP sensors not listed above can also be used, but they must be configured in the Terminator X software.

NOTE: The max manifold pressure supported by the handheld base calibrations is 250 kPa (21.6 psi boost).

NOTE: The following plug and play MAP adapter harnesses are available:

- MPFI to Holley SS MAP Adapter Harness – 558-466
- LS1/2 to Holley SS MAP Adapter Harness – 558-467
- LS1/2 to LS3 MAP Adapter Harness – 558-416



Figure 16 MAP

9.3.9 Throttle Position Sensor (TPS)

[Required] Connect to a cable driven throttle body.

Note: This connector is not used with a Drive-By-Wire throttle body.



Figure 17 TPS

9.3.10 Idle Air Control (IAC)

[Required] Connect to a cable driven throttle body.

Note: This connector is not used with a Drive-By-Wire throttle body.




Figure 18 IAC

9.3.11 Fuel Injectors

[Required] All terminated harnesses have a fuel injector connector. For all DI applications, the fuel injector connector will be plugged into the DI subharness.

Note that for engines with different firing orders, you do NOT change these pins. The engine's firing order is input in the software itself. Pin's A-H are routed to the cylinder number designation for the engine (i.e. A goes to cylinder #1, B goes to cylinder #2, etc).




Figure 19 Fuel Injectors

NOTE: Make sure to connect each injector connector (numbered) into the appropriate fuel injector otherwise severe engine damage may occur.

9.3.12 Ignition Coils

[Not present on all harnesses] Connect the coil connectors into each bank of coils. The driver side connector should be labeled "DIS CONNECTOR ODD" or have the corresponding cylinder numbers. The passenger side connector should be labeled "DIS CONNECTOR EVEN" or have the corresponding cylinder numbers. Make sure these are plugged in correctly. If they aren't, the firing order will not occur properly and damage could result.




Figure 20 Ignition Even




Figure 21 Ignition Odd

9.3.13 Coil Ground Wires

[Not present on all harnesses] There are two coil ground wires. These are labeled "CONNECT TO CYLINDER HEAD ONLY!" There is one on each bank of the engine. They are black wires and have an eyelet crimped on them. These are to be fastened to the rear of each cylinder head. These MUST be installed and MUST be installed to the head securely. If not, the coils will not be grounded and the engine will run poorly and other issues will occur.



Figure 22 Coil Ground Wires

9.3.14 Handheld Connections - (CAN1)

[Required] The handheld controller is used to create an initial calibration for the system, allows for simple tuning changes to be performed, and is also used to view various information of the EFI system. It should be installed such that the handheld controller can be easily used in the passenger compartment. The handheld plugs directly into the main harness at either connector labeled "CAN". The handheld does not have to remain in the vehicle or utilized after the vehicle is set up and running properly.




Figure 23 Handheld Connection



Figure 24 Handheld




Figure 25 – Handheld CAN connector

10.0 LOOSE WIRES



Figure 26

The following loose wires in the main wiring harness should be connected as follows on all systems.

[Required] 12V Switched – Color = Red/White – Should be connected to a clean +12 volt power source. Power source should only be active when the ignition is on. Make sure source has power when engine is cranking as well (check with voltmeter). Not all sources apply power when the ignition switch is in “cranking” position. This wire is located approximately 7” from the ECU connectors. **DO NOT connect to a “DIRTY” source like an ignition coil!**

[Required] 12V Battery – Color = Red – Should be connected directly to the battery. This powers the fuel pump and fuel injectors. This wire is protected by a fuse in a sealed fuse holder. The fuse holder is located about 18” from the ECU connector. A fuse is pre-installed (20A).

[Optional] 12V Fuel Pump – Color = Green - Used to directly power a fuel pump (+12 volt). **Do not use this wire to power fuel pumps that require over 15 Amps.** Refer to your fuel pump manufacturer for amperage ratings. For high current pumps, use this wire to trigger a separate relay and use larger gauge wire to feed the pump - 10 gauge is recommended.

[Required] Chassis Ground – Color = Black – Connect to a chassis ground point that has excellent connectivity with both the engine and battery. There must be good continuity between the connection point and the battery when checked with a digital volt ohm meter (DVOM). This ground should not be connected at the same location as other grounds.

[Optional] Points Output – Color = White – Used to trigger a CD ignition box in certain applications. This will not be used with a TFI distributor. If using a TFI distributor and a CD ignition box, you will connect the white points output wire from the **TFI adapter harness** to the CD box. See ignition wiring diagrams at the end of this manual. **Note:** This loose wire is not present on all harnesses.

[Optional] Tach Output – Color = Blue with white stripe – This wire provides a 12v square wave output and can be used to trigger a conventional tachometer. **Note:** This loose wire is not present on all harnesses.

[Optional] “Coil – ” – Color = Yellow – Used for an RPM input signal when not controlling timing and NOT running a Capacitive Discharge (MSD) ignition system. **Note:** This loose wire is not present on all harnesses

11.0 ADDITIONAL INPUTS & OUTPUTS

Terminator X base calibrations from the wizard in the handheld are pre-configured with 3 outputs and 1 input to be used for the following features:

- Electric Fan #1 output (Ground)
- Electric Fan #2 output (Ground)
- Air Conditioning Shutdown at wide open throttle (Ground)
- A/C Kick input (Ground)

The chart below will help identify the proper loose wires necessary for use with the preconfigured inputs/outputs, as well as additional inputs/outputs that can be configured in the software. These are located in the "Inputs/Outputs" connector (**Figure 27**). A mating harness with loose wires is included with the system (**Figure 28**).

Preconfigured Input/Output Wiring			
Description	ECU Pin	Connector Pin	Loose Wire Color
A/C Kick (Input #1)	A12	A	White w/ Blue
Input #2	A3	B	White w/ Red
Input #3	A13	C	White w/ Black
Input #4	A4	D	White w/ Green
Electric Fan #1 (Output #1)	B12	E	Gray w/ Yellow
Electric Fan #2 (Output #2)	B11	F	Gray w/ Red
A/C Shutdown (Output #3)	B10	G	Gray w/ Black
Output #4*	B3	H	Gray w/ Green

*Applications using an OEM dual stage oil pump use one of the Terminator X outputs (Output #4) to control the oil pressure. If using the GM LTx Main Harness (PN 558-129), Output #4 is already connected from the ECU to the oil pump.

The following indicates proper wiring for these features:

Electric Fan #1 output – This output will provide a ground output to trigger a relay used for a cooling fan. This output should never be directly connected to a fan, but the relay that powers the fan. It should be connected to the ground trigger of the relay.

Electric Fan #2 output – This output will provide a ground output to trigger a relay used for a cooling fan. This output should never be directly connected to a fan, but the relay that powers the fan. It should be connected to the ground trigger of the relay.

A/C Shutdown – This output will provide a ground output at a defined throttle position. If desired, this throttle position can be changed using the software. This output can be used to trigger a relay that deactivates the A/C at higher throttle positions. This may require the installation of a 5 pole relay in the existing A/C wiring.

A/C Kick input – This ground input will allow for the Idle Air Control motor to automatically make an increase in IAC %, which is necessary to avoid a momentary drop in idle speed when the A/C compressor turns on.




Figure 27



Figure 28

12.0 TRANSMISSION HARNESS

12.1 GM Transmission Wiring

The 558-405 GM transmission harness can be used on 4L60E, 4L65E, early 4L70E, 4L80E, and 4L85E transmissions. Each connector should be labeled.

Connectors

ECU Connector (J4) – Plugs into the ECU. Plugs into the last connector opposite the main harness.

Main Transmission Connector – Simply plugs into the connector on the transmission. Located on the driver's side of a 4L80E (installed horizontally) and the passenger side on a 4L60E (installed vertically).

Vehicle Speed Sensor (VSS)/Transmission Output Speed Sensor (OSS) – Located on the rear drivers side on a 4L80E and the rear passengers side on a 4L60E

Turbine Speed Sensor – The 4L60E does not have a turbine speed sensor. It is located towards the front driver's side on a 4L80E. Note that a 4L70E has one internally wired, but is not connected to the Holley harness. The turbine speed sensor is not used for any calculations in the ECU, just for monitoring purposes.

Loose Wires

Brake Switch (Grey) – Wired to the brake light switch. This must be installed to a +12v source (as most brake light switches are). This input is used to unlock the torque converter when the brakes are applied.

Ground (Black) – Connect to a good chassis/engine ground source

Power (Red) – Supplies power to the transmission solenoids. This should be connected directly to the battery, or a constant battery source capable of supplying 5 amps.

Switched Power (Red/White) – This should be connected to a +12v switched power source and is used to trigger the relay

NOTE: The power supplying this wire must **NOT** be tied to the same point that the ECU switched power wire (red/white wire) is connected to. If they are tied together, the transmission power could back-feed power to the ECU and the ECU/engine will not shut off when the key is turned off. Use a relay or separate switched ignition power pickup point to supply power to the transmission harness.




Figure 29 - Main Transmission Connector



Figure 30 - Vehicle Speed Sensor



Figure 31 - Turbine Speed Sensor



Figure 32 - Transmission & ECU Connector



Figure 33 - Loose Wire Bundle

12.2 Ford Transmission Wiring

There are two different Ford transmissions harnesses, depending on the application:

- 1.) AODE and 4R70W transmissions from 1992 until 1997
- 2.) 4R70W and 4R75W transmissions from 1998 and up




Figure 34 - Main Transmission Connector
AODE/4R70W 92-97



Figure 35 - Main Transmission Connector
4R70W/4R75W 98+

Connectors

ECU Connector (J4) – Plugs into the ECU. Plugs into the last connector opposite the main harness.

Main Transmission Connector – Simply plugs into the connector on the transmission.

Transmission Range Connector – Plugs in at the manual lever on the transmission. The loose wires are for various car features and are listed later in the instructions.

Vehicle Speed Sensor (VSS)/Transmission Output Speed Sensor (OSS) –
92-97 Harness: Plugs in to the speed sensor located on the tailshaft of the transmission.

98+ Harness: Two short jumper harnesses are included – select the correct one for your application based on the sensor's connector shape.

Pressure Transducer (optional) – The harness is supplied with a prewired pressure transducer connector. This can be used to monitor transmission line pressure if desired. The input will need to be configured for the sensor used in the I/O and then mapped to J4-B21. A Holley 0-500psi sensor (554-136) is recommended.

Loose Wires

Brake Switch (brown/white) – Wired to the brake light switch. This must be installed to a +12v source (as most brake light switches are). This input is used to unlock the torque converter when the brakes are applied.

OD Cancel (tan) (optional) – Use this wire on a momentary switch to disable/enable overdrive. This must be installed to a +12v.

OD Status (light blue) (optional) – Hook this to the ground side of an LED to indicate if OD Cancel is active.

Reverse Lights (violet) – Pass through circuit for reverse lamp activation.

Neutral Safety Switch (white) – Pass through circuit for starter solenoid.

4x4 Module (black/white) (optional) – Pass through circuit for 4x4 modules.

NOTE: Refer to factory manuals in order to wire these functions into factory vehicles equipped with these functions.

13.0 DRIVE-BY-WIRE HARNESS

13.1 Overview

The Terminator X Max ECU has built-in capability to control OEM type Drive-By-Wire throttle pedals and throttle bodies for aftermarket installation.

To ensure a safe and reliable installation, there are certain hardware requirements that **must** be followed:

See Appendix 3.0 in the full Terminator X instruction manual found on for a listing of factory drive-by-wire throttle bodies and pedals that have been pre-calibrated and approved for use with this harness

13.2 Warnings!

Use only the drive-by-wire wiring harness supplied by Holley. THIS HARNESS CAN NOT BE CUT, SHORTENED, LENGTHENED, TAILORED, OR MODIFIED UNDER ANY CIRCUMSTANCE! THE HARNESS CONTAINS PROTECTIVE SHIELDING / GROUNDED CABLING TO ENSURE PROPER OPERATION. DO NOT REMOVE OR MODIFY THE PROTECTIVE SHEATHING UNDER ANY CIRCUMSTANCES. HOLLEY ASSUMES NO LIABILITY FOR ANY INSTANCES ARISING DUE TO USE OF THROTTLE PEDALS, THROTTLE BODIES OR ASSOCIATED COMPONENTS NOT SPECIFICALLY APPROVED BY HOLLEY.

13.3 Installation

Installation of both the drive-by-wire throttle body and pedal assembly should be performed by a professional, competent mechanic. It is important that the installation of both the throttle body and pedal assembly on an engine (not originally equipped with these components) be done in such a manner that assures proper operation of both components as intended by the OEM manufacturer.

- The throttle body must be installed in such a manner that the throttle plate(s) are allowed to rotate freely.
- The pedal assembly must also be installed in such a manner that it is rigidly and securely mounted, yet does not put the pedal in a bind, or put any mechanical stress on the electrical and electronic components. Proper positioning of the pedal is of the utmost importance.
- The accelerator pedal must have adequate clearance throughout the range of its travel to prevent the possibility of the pedal coming in contact with any item that may cause it not to return to the "idle" position upon release. The accelerator pedal must also be mounted far enough away from the brake pedal as to allow for the vehicle's brakes to be fully applied without the operator's foot coming in contact with the D-B-W pedal.
- The drive-by-wire pedal should be in a position such that it is lower than the brake pedal when the brake pedal is depressed.
- Installation of the wiring harness supplied by Holley must be done so that there is no chance the wiring may be cut or abraded. Rubber grommets should be utilized wherever the harness passes thru a firewall / sheet metal panel.
- The DBW harness should never be routed in such a manner that it may come in contact with "noisy" electrical components or wiring that may emit RFI and/or EMI noise. Typical "noisy" components and associated wiring in a vehicle would be spark plug wires, ignition coils, high energy ignition boxes, two-way radios (including CB's), etc. Maintain a minimum of 5" of clearance to any of these types of components.

The harness is designed to be "plug-and-play" with the throttle bodies and pedal assembly indicated above. It should not be used for any other applications.

13.4 System Safeties

Holley designed the drive-by-wire system to utilize a brake pedal switch input. This is wired to a +12v input from the brake pedal switch. If the brake pedal is depressed enough to activate the brake light switch, the following occurs:

- The ECU will not allow a throttle position over 10%, no matter how far the pedal is pushed. This consequently limits the opening of the throttle body.

Before a pedal value over 10% will be recognized, the following must occur in this order:

- Brake pedal switch must be released
- Pedal position must go below 10%

- Fuel flow is limited to 30 lb./hr. as an additional safety.

IMPORTANT! INSTALLATION OF THIS SAFETY CIRCUIT IS REQUIRED WHEN USING THE DRIVE-BY-WIRE FEATURE! DEFEATING OR NEGLECTING TO INSTALL THIS INPUT IS DONE SO AT THE USERS OWN RISK. THE USER ASSUMES ANY AND ALL LIABILITY FOR ANY DAMAGE, AS A RESULT OF A DRIVE-BY-WIRE MALFUNCTION.

Most drive-by-wire systems are designed so there are two position sensors on both the throttle body and the accelerator pedal assembly. This is done as a failsafe in the event that one of the position sensors should fail. Holley EFI systems require that both sets of sensors are functioning 100% properly. If any sensor moves from its calibrated position, the throttle body is immediately de-powered, forcing it to move to the factory "limp home" position. The "limp home" position is described in detail below. Whenever a fault is detected and the throttle body is de-powered, a fuel flow limit of 30 lb./hr. is also introduced.

13.5 Throttle Body “Limp Home” Position

Factory Drive-By-Wire Throttle Bodies have a “Limp Home” position. This is the position that the throttle body is at when no power is applied. It is typically enough air flow to allow a car to move at a speed of approximately 45 mph.

It should be strongly noted that this position allows MORE airflow than the engine uses for an idle position. If the throttle body goes into a “limp home” position due to a sensor failure or other reason, the engine will have more air and result in more power. This will require more brake pressure to be applied if a vehicle is in gear so that it does not move.

13.6 Drive-By-Wire DO’S and DON’TS

DO

- Use only the Holley supplied harness.
- Have the pedal, throttle body, and harness installed by a competent professional.

DON’T

- Do not use wire other than the Holley supplied harness.
- Do not cut, shorten, lengthen, or otherwise modify the drive-by-wire harness for any reason!
- Do not run drive-by-wire harness past high voltage or “noisy” sources
- Do not use this system if the pedal is not securely mounted as described in the instructions above. It must be SOLIDLY mounted with adequate room for safe and proper operation.
- Do not use this system if the throttle body is not properly mounted or has any potential of interference/binding of the throttle plates.
- Do not start the engine unless everything is operating properly.

13.7 GM DBW Wiring

Golden Rule: These are plug-and-play harnesses. If they don’t plug, don’t play.

LS Engines came with two styles of connectors for their DBW throttle bodies; An 8 pin connector (early LS trucks) and a 6 pin (passenger car and 2007+ truck).

LT Engines all share a common connector, the supplied LTx DBW harness includes a pedal assembly that can be used with the LS pedal assembly.

Appendix 3 of the full Terminator X instruction manual found contains more details and Holley supported part numbers for throttle bodies and throttle pedals and their associated harness part numbers.



Figure 36

ECU connector – plug into location J3 (See Section 9.1 – ECU pic)

Pedal Connector – plug into the throttle pedal

Throttle Body Connector – plug into the DBW throttle body.

Brake Switch Wire – This **MUST** be connected to a +12v input from the brake pedal switch.

ECU connector – plug into location J3 (See Section 9.1 – ECU pic)

Pedal Connector – plug into the throttle pedal

Throttle Body Connector – plug into the DBW throttle body.

Brake Switch Wire – This **MUST** be connected to a +12v input from the brake pedal switch.

Supported Throttle Bodies – these are the most recent part numbers, older engines may have PNs that are superseded by these part numbers

LTx Part Numbers	LSx Part Numbers	Supported Pedal Assemblies
12617792 (L83)	12570790, 12570800, 12580195,	Pedal Assembly - 10379038
12678223 (L86, LT1, LT4)	12580760, 12605109, 12629992	

14.0 FINAL ECU CONNECTION

Once all harnessing has been connected, you may plug in the main power harnesses (referenced in section 9.1) to the ECU.

At this point, the installation of your EFI system should be 100 percent complete. The ECU, TERMINATOR X™ Handheld controller, throttle body and intake hardware, all sensors, wiring, fuel pump, regulator and return line, and all other hardware should be installed. The vehicle should be ready to start and run. If this is not the case, refer to the hardware installation manual included with your particular system.

15.0 TERMINATOR X™ INSTRUCTIONS AND TUNING

The TERMINATOR X™ EFI systems are designed to be easy to use for the first time EFI tuner. The instructions are set up in that manner as well. These instructions will not get into detail about EFI theory and operation. They will provide the steps necessary to get you up and running quickly. The TERMINATOR X™ system allows for the user to perform some basic changes to the tuning *if they desire to do so*. The instructions are sequenced to get you up and running so you can enjoy your vehicle, then review some of the parameters that can be adjusted to fine tune your vehicle at a later time if desired.

16.0 INITIAL POWER-UP

Turn the ignition key to the “run” position. This should apply power to the ECU as well as the TERMINATOR X™ Handheld control module. The handheld should power up and the Home Screen (**Figure 37**) should appear.

The Home screen contains icons which will navigate to different functional features of the 3.5 Touch Screen. These features will be discussed in detail throughout this manual.




Figure 37 – Home Screen

NOTE: DO NOT ATTEMPT TO START THE VEHICLE UNTIL YOU ARE TOLD TO DO SO IN THE INSTRUCTIONS BELOW.

NOTE: The handheld has an SD memory card installed in the side. This card contains specific information that is required for the use of the TERMINATOR X™ product. DO NOT replace this card with another. There should be no need to remove this card for normal use.

17.0 HANDHELD NAVIGATION & USE

The 3.5” handheld utilizes a touch screen display. All navigation is done through “touching” an icon or button on the screen. The following is an overview of the different types of adjustment screens that are used in the display, and that may be utilized when tuning or making selections.

17.1 Making Adjustments

Slider Bar: Slide the bar left or right with the stylus, or use the right and left arrow keys for fine adjustment (**Figure 38**).

List: Use the scroll bar on the right hand side of the screen to view all list entries. Touch the desired list item and click ‘OK’ to make a selection (**Figure 39**).




Figure 38 – Slider Bar




Figure 39 – List

Radio Button: Touch the desired list item to select it (Figure 40).

On Screen Prompts: Follow the on screen text and use buttons at the bottom of the screen to continue or confirm (Figure 41).



Figure 40 – On Screen Prompts




Figure 41 – Graph




Figure 42 – Edit Options

Digitally: Selecting this option enables slider bar adjustment of individual data points on the graph or the entire curve.

Graphically: Selecting this option enables single point or whole curve adjustment. A stylus may be used to select and drag data on the graph screen.

Entire Curve: Selecting this will 'lock' all the data points together allowing the entire curve to be shifted up or down

Point by Point: Selecting this will allow point by point curve adjustment for fine tuning.

Live Data 1 & 2: This will enable live telemetry on the graph screen making fine tuning easier.

18.0 HOME SCREEN

The HOME SCREEN has 6 selections (Figure 43). They are explained in more detail later in the instructions.

TUNING – Allows for various parameters to be easily adjusted.

MONITOR – A variety of gauge and dash displays.

ADVANCED FEATURES – Advanced / Power Adder tuning

LOGGING – Start, Stop, and Configure Data Logs

FILE – Saves and loads calibrations. Also shows information about the ECU and handheld controller.

WIZARDS – Creates a base calibration and performs the TPS Autaset function.





Figure 43


19.0 CALIBRATION WIZARD




The Terminator X system will build a custom calibration for your engine based on a few easy to answer questions. To begin, Choose the Wizards icon from the main menu.




Choose the GCF Wizard icon.




Choose DIRECT INJECTION as the system type.



Choose proper system type if listed, otherwise choose "Universal".



Choose the number of cylinders - 4, 6, & 8 are options.



Choose the correct firing order. Use the scroll bar on the right to view all options.



Chose the unit of measure you would like to use to enter the engine size.




Use the slider bar to enter your engine size.



Use the slider bar to set your desired HOT idle speed.


Tip: The Terminator X system will target this idle speed when coolant temp is above 160° F



Make a selection that matches the cam specs of your engine.


Tip: If you do not know your exact camshaft specs, choose selection #1

Tip: Closed Loop operation is disabled below 2500 RPM when #3 is chosen. This can be modified per your needs via the included 3.5" handheld




Choose your ignition type:
GM GEN V LTx w/ VVT
GM GEN V LTx Non-VVT

Tip: The kit & engine harness you purchased must match your application.




Choose your engine:
L83
L86
LT1



Choose the appropriate fuel pressure.

This is the fuel pressure before your Direct Injection Pump.




Choose your brand/manufacturer of injector.



Choose the part number of injector that matches what is installed in your engine.

Tip: For proper operation, it is critical that the correct injector part number is selected

Tip: Injector data can be entered and modified via Terminator X software if your injectors are not listed.



Choose your power adder type.

Tip: Users selecting naturally aspirated during this step will skip to "Choose throttle body type" on the next page.

Naturally Aspirated & Nitrous

Turbo and Supercharger

Depending on your power adder type you will get these two options for MAP sensor.




Tip: Terminator X base calibrations require using one of the listed part numbers for a MAP sensor. Failure to do so may cause severe engine damage.

Tip: MAP sensors other than those listed may be configured via Terminator X software.

Note: The max manifold pressure supported by the handheld base calibrations is 250 kPa (21.6 psi) boost. If your application makes more boost, tuning with the PC software is required.



If a Turbo or Supercharger was chosen, use the slider bar to set desired wide open throttle (WOT) ignition timing **AT ZERO BOOST**




If a Turbo or Supercharger was chosen, use the slider bar to set desired timing retard per pound of boost.

Breakpoints of 7, 14 & 21 PSI are shown for reference



If a Turbo or Supercharger was chosen, use the slider bar to set desired wide open throttle (WOT) Air/Fuel Ratio (AFR) **AT ZERO BOOST**



If a Turbo or Supercharger was chosen, use the slider bar to set desired AFR offset per 7 pounds of boost.

Breakpoints of 7, 14 & 21 PSI are shown for reference




Choose throttle body type (Terminator X Max only)

Select No if you are using a cable operated throttle body



If using a cable operated throttle body, choose IAC type.



If you will be using the Terminator X system to control an electronic transmission (Terminator X Max only), choose Yes.

Choose no if you have an older non-electronic transmission (i.e. TH350, TH400, 700R-4, etc.) OR if you are using a separate standalone controller for your previously installed electronic transmission.



If transmission control was chosen in the previous step, Select the transmission type you will be controlling. The following options are available:

- 4L60/5E
- 4L70E
- 4L80/5E
- Ford AODE
- Ford 4R70W




Enter your tire diameter



Enter your gear ratio

Tip: Tire diameter and gear ratio must be entered correctly for proper transmission operation



Select the Start button to upload the custom Terminator X calibration to your ECU.

Congratulations, you have completed the setup Wizard!

It is now time to perform a TPS Autoset

20.0 TPS AUTOSET

After completing the calibration wizard, the next step is to perform a "TPS Autaset". **This must be done on a brand new system otherwise the injectors and ignition will not be fired by the ECU.** A TPS Autaset programs the ECU with the full travel/voltage range from idle to wide open throttle for the Throttle Position Sensor (TPS). This must be done with the vehicle ignition power on. The TPS Autaset function is found under the "WIZARDS" choice under the HOME SCREEN. Select "START TPS AUTOSET". Follow the prompts. You can select "Home" at any point to stop the process. If everything is successful, you will see a TPS Autaset Successful message.



Step 1: Select TPS Autaset



Step 2



Step 3



Step 4: Select 'Done'

21.0 SENSOR VERIFICATION

Before starting the vehicle, verify that all of the sensors are reading properly. Turn the key off, and cycle it back on. At this time you should hear the fuel pump come on and run for 5 seconds. Check for fuel leaks.

On the HOME SCREEN, select the MONITOR tab. This will bring up various options. Select the "Monitors" screen. You will see a screen called "Initial Startup". Select this. With the key on and the engine off, these sensors should read as follows:

- **Engine RPM** – Will show "Stall" when not cranking. Will show RPM once the engine is cranking or running
- **MAP** (Manifold Air Pressure Sensor) – Should read from 95-102. At high elevations, it could read as low as 75.
- **TPS** (Throttle Position Sensor) – Slowly depress the throttle to wide open. It should read 100 at wide open throttle. Cable operated throttle bodies should read 0 closed.
- **CTS** (Coolant Temperature Sensor) – reads engine temperature. If the engine is "cold", it should read close to ambient temperature.
- **Battery** – Will read battery voltage. Should be 12.0 volts minimum.

If ANY of these sensors are not reading properly DO NOT attempt to start the engine.

22.0 STARTUP

The vehicle should be ready to be started. Open the same sensors screen as in section 21.0. Make sure the TPS is reading 0. If it does not, do a TPS AUTOSET, or if it is reading 1-2%, close the idle screw on the throttle body slightly.

Crank the engine and look at the RPM parameter. It should change to "Syncing", indicating the ECU is syncing with the RPM signal for an instant, then show an RPM signal. The engine should fire and run and come to an idle.

If you do not get an RPM signal, there is an error in the wiring or system setup. Call Holley Tech service for advice.

If the engine starts but is idling too low and appears to be struggling for air, refer to section 24.0 for cable operated throttle bodies.

23.0 AFTER-STARTUP

Once the vehicle has started, look for any fuel or coolant leaks. Let the vehicle warm up and look at some other parameters to make everything is operating properly. Go into the MONITOR, MONITORS, and select the "Closed Loop" icon.

- **Closed Loop Status** – Indicates whether the engine is "Closed Loop" or "Open Loop". Closed Loop indicates that the ECU is adding or subtracting fuel to maintain the target air/fuel ratio. The TERMINATOR™ calibrations are such that the system should be operating closed loop almost all of the time.
- **Closed Loop Compensation** – This is the percentage of fuel that the ECU is adding or subtracting to maintain the target air/fuel ratio at any specific moment. A value with a minus (-) sign in front indicates the ECU is removing fuel. A value with no minus sign indicates the ECU is adding fuel. When in open loop operation, this will always stay at 0%.
- **Target Air/Fuel Ratio** – This is the target AFR (air/fuel ratio) the ECU is trying to maintain. This will vary depending on the engine speed and load.
- **Air/Fuel Ratio Left** – This will show the air/fuel ratio the wideband oxygen sensor is reading. The Closed Loop Compensation should be adding or subtracting fuel all the time such that the AFR Left should always be close to the Target AFR value. (Note ARF Right will only be active if a second sensor is being used which is not included).
- **Fuel Learn Status** – This indicates the status of the TERMINATOR™ "Self Tuning" operation (Learn Status). The system will automatically tune itself as you drive around. There are several conditions that must occur in order for the Self Tuning to occur. The engine temperature must exceed 160° F. The system must be operating in a closed loop mode, and the Self Tuning must be enabled. The base TERMINATOR™ setups have the Self Tuning enabled. Once the engine reaches 160° F, the Self Tuning should be active. The Learn Stat will show "NoLearn" when Self Tuning is not active and "Learn" if Self-tuning is active.

If any of these parameters are not showing a proper value, find out why before further driving the vehicle.

24.0 IDLE SETTING/CABLE OPERATED THROTTLE PLATE SETTING

Once the engine is up to operating temperature, the idle speed can be set to what is desired.

From the HOME SCREEN, select the TUNING tab. Then select the BASIC and then BASIC IDLE. You can see what the target hot idle speed is set to. If you are happy with the current value, use the BACK or HOME button to exit. If you would like to change it, click on the IDLE SPEED. This brings up a screen to adjust the idle speed (**Figure 44**). Move the button left and right to adjust it. Click the button to save the new value or select CANCEL at the bottom to move out of this screen.




Figure 44

Whether you change the target idle or not, you need to set the throttle plates on the throttle body to an optimal position. To do so, with the engine running select the MONITOR tab. You will see the IDLE screen. Look at the "IAC Position" value. This value should be set

between 2 and 10 with the engine in neutral and up to operating temperature. Also make sure the “TPS” value is showing a value of 0. If it is not, you need to perform a TPS AUTOSET.

If the “IAC Position” value is showing zero, you must close the throttle plates until it reads a value of 2-10. Slowly turn the throttle shaft adjustment screw on the throttle body out (counter-clockwise). If the IAC position is “stuck” at 0, it is likely that the engine is idling at a higher speed than you have set the target idle speed for. You need to adjust the throttle plates to resolve this issue.

If the “IAC Position” value is greater than 10, it is a good idea to open (turn the throttle shaft adjustment screw in, clockwise) the throttle plates until the “IAC Position” value is between 2 and 10. Note that if you open the throttle plates such that the “TPS” position goes above a value of 0, you will need to shut the vehicle off and perform a TPS AUTOSET. Then restart the vehicle and continue adjusting the throttle plates. Once the TPS goes above a value of 0, the ECU goes out of its “idle” mode and will lock the IAC Position to a fixed value.

When the adjustments are completed, make sure the TPS reads a value of 0 with the engine idling.

25.0 SELF-TUNING

At this point, it is time to just drive the vehicle and let the system perform its self-tuning process. The best way for this is to drive the vehicle under as many different operating conditions as possible. Different engine speeds and loads. Start by slowly revving the engine up in neutral and holding it at different speeds up to 2500 RPM. This will help the system learn these points. Then drive the vehicle, possibly using different transmission gears to learn in different areas. If you have an automatic transmission you may want to put it in gear, and with your foot on the brake pedal, apply a SMALL amount of throttle so that the system learns in this area as well.

NOTE: There are several conditions where Learning will NOT occur. They are the following:

- If the engine is below 160° F
- When the engine sees quick accelerator pedal movement
- Certain times when the accelerator pedal is lifted and the vehicle is coasting
- If the learn is disabled by the user

If you are interested in seeing if Self Tuning is completed in a certain area, you can look at the following:

- Select MONITORS from the HOME SCREEN
- Select the LEARN icon
- The FUEL LEARN STATUS indicates if the learn feature is active. The FUEL LEARN PERCENT indicates what the learn value is.
- Look at the CLOSED LOOP COMPENSATION value. Once this value is close to zero, learning is complete in an area.

At this point you can drive and enjoy your TERMINATOR X™ EFI as it is. The full instruction and tuning manual can be found on the product pages and describes in detail how you can adjust various parameters to further optimize fuel economy and overall performance, if desired.

27.0 DIAGNOSTIC LED'S

Terminator X ECU LED Reference Chart


LED#	Function	Color	Definition
1	Heartbeat	Green/Flash	ECU is powered
2	Engine running	Green	Engine is running
		Yellow	Engine is not running
3	Wideband status	Blue	too hot, too cold, slow warmup, uncalibrated
		Green	sensor is active and functioning properly
		Red	sensor is open or needs to be replaced
		Yellow	sensor is heating
		Off	sensor is disabled
4	TPS calibrated	Green	Calibrated
		Red	If DBW = Pedal & TB Calibration Error
			If non DBW - Calibration Error
		Cyan	DBW Pedal Calibration Error
		Purple	DBW TB Calibration Error
5	Off/undefined		Future
6	Crank	Green	When below Crank to Run RPM, tooth detected
		Blue	When below Crank to Run RPM, gap detected
		Red	Crank error detected -If engine continues to run, will stay Red until ECU is powered off -If engine shuts off due to severe signal loss, will stay Red until RPM re-sync OR key cycle
		Off	When above Crank to Run RPM and ECU is properly syncd
7	Cam	Green	When below Crank to Run RPM, tooth detected
		Blue	When below Crank to Run RPM, gap detected
		Red	Cam error detected -If engine continues to run, will stay Red until ECU is powered off -If engine shuts off due to severe signal loss, will stay Red until RPM re-sync OR key cycle
		Off	When above Crank to Run RPM and ECU is properly syncd
8	Off/undefined		Future

GDI LED Reference Chart

LED #	FUNCTIONS	Color	Definition
1	Heartbeat	Green - flashing 1 sec on / off	ECU is Powered
2	Sync Status	Green	Engine is running and crank and cam sensor are working properly
		Blue	No RPM detected
		Red - flashing 1 sec on / off	Error with crank or cam sensor
3	VVT	Green	VVT working normally
		Red	VVT Error detected resets with key cycle
			Cam was not able to meet target position
4	Pump Control	Green	High Pressure pump is functioning normally
		Red	Error with high pressure pump Resets with key cycle
5	DI injectors	Green	DI Injectors functioning normally
		Red	DI Injector error resets with key cycle
			Short/open circuit detected
			Overlapping injection event
6	Off/Undefined		Future
7	Off/Undefined		Future
8	Off/Undefined		Future

TERMINATOR[™]X

TERMINATOR[™]X MAX



Gasoline Direct Injection Controller: GM Gen V LTx

Min Software Version: Term X V2 build 20

Overview

Wiring

Fuel Pressure Sensor Differences

Software

DI Target Fuel Pressure

VCT Tables

Injector Phasing

Inputs/Outputs

Diagnostics

LED Diagnostic Functions

Overview:

The GDI Controller is designed to work in tandem with Holley Terminator X ECUs to control GM Gen V engines. It provides various functions such as fuel rail pressure control, variable cam timing, and diagnostic information via the Terminator X V2 Software. On stock engines the Terminator X handheld can be used to setup the calibration meaning that no laptop is required.

Wiring

The Wiring Harness for the GDI Controller has 5 main connections.

GDI Controller Connectors – These two connectors plug into the GDI Controller

INJ ODD and EVEN Connections – these two connectors plug into their respective bank of the engine injector sub harnesses and control the injectors, high pressure pump, as well as read rail pressure.

Injector Inputs Connection – This plugs directly into the injector connector on the engine main harness and is what tells the GDI controller how much fuel to inject

Bulkhead – This also plugs into the engine main harness GDI connector and carries all of the shared signals between the two harnesses.

Fuel Pressure Sensor Differences:

There are two different fuel pressure sensors that GM uses with the Gen V LTx engines. Depending on which one your engine has will determine which kit/harness is required. The Sensor is mounted to the back of the driver side fuel rail (as shown below). Compare your sensor to the pictures below to determine if you have an early or late sensor.

WARNING! This type of work **MUST** be performed in a well-ventilated area. Do not smoke or have an open flame present near gasoline vapors or an explosion may result.

NOTE: The fuel rail pressure sensor and the matching fuel rail have different tapers to seal the fuel. They can NOT be swapped without using the matching fuel rail. A high pressure leak and fire can result if you use the incorrect rail pressure sensor.



EARLY



LATE



EARLY




LATE

Software:

Several new options have been added under the system ICF including a new injection type, new crank and cam options, a Variable Cam Timing option, and revisions to the DI Target Fuel Pressure.

Engine Setup -

Direct Injection has been added as a new injection type. It enables the DI Target Fuel Pressure Table as well as changes the rest of the engine setup to a direct injection specific layout.



VCT Tables

The VCT Tables are prepopulated with data for each of the Gen V engines. There is also a custom option, which simply unlocks the currently selected table. For example, if you want to modify the VCT table but think the L83 table is a good starting point then make sure to select the L83 option and then the custom option to unlock it.

NOTE: Changing the cam position can have a large effect on airflow. Care should be taken to retune fuel and spark after making changes to the VCT table.

SYSTEM PARAMETERS ^ x

ECU Configuration

Engine Parameters

Ignition Parameters

Dwell Time

Sensor Scaling/Warnings +

Basic I/O +

Closed Loop/Learn +

Variable Cam Timing

DI Target Fuel Pressure

Injector Phasing

Individual Cylinder

Inputs/Outputs

SETUP

Enable

Engine Type GM Gen V LTx

Engine Subtype L83

CAM SETTINGS

Graph X Axis RPM Y Axis Grams/Cyl

	0.60	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	0.0	2.0	2.0	3.0	4.0	4.0	6.0	8.0
	0.52	0.0	1.0	4.0	5.0	7.0	8.0	9.0	9.0	9.0	6.0	7.0	5.0	5.0	5.0	6.0	6.0
	0.48	0.0	3.0	7.0	9.0	11.0	11.0	12.0	13.0	11.0	8.0	8.0	6.0	6.0	6.0	6.0	6.0
	0.44	0.0	6.0	11.0	15.0	14.0	15.0	15.0	16.0	12.0	10.0	6.0	7.0	7.0	7.0	7.0	7.0
	0.40	0.0	7.0	14.0	16.0	16.0	17.0	18.0	18.0	14.0	12.0	10.0	11.0	7.0	7.0	7.0	7.0
	0.36	0.0	9.0	16.0	18.0	19.0	20.0	20.0	21.0	17.0	13.0	12.0	12.0	10.0	10.0	8.0	8.0
	0.32	0.0	11.0	18.0	21.0	22.0	22.0	23.0	23.0	18.0	15.0	14.0	12.0	12.0	12.0	10.0	8.0
	0.28	0.0	15.0	22.0	24.0	24.0	25.0	24.0	23.0	18.0	17.0	17.0	17.0	18.0	20.0	12.0	13.0
	0.24	0.0	15.0	20.0	24.0	24.0	24.0	25.0	26.0	22.0	19.0	20.0	22.0	22.0	28.0	18.0	15.0
	0.20	0.0	11.0	17.0	20.0	24.0	24.0	24.0	25.0	24.0	23.0	24.0	28.0	28.0	28.0	23.0	20.0
	0.16	0.0	4.0	6.0	10.0	12.0	14.0	16.0	22.0	24.0	24.0	28.0	28.0	27.0	28.0	26.0	18.0
	0.14	0.0	2.0	5.0	6.0	8.0	9.0	11.0	16.0	18.0	18.0	20.0	20.0	21.0	20.0	20.0	16.0
	0.12	0.0	0.0	2.0	2.0	3.0	4.0	6.0	10.0	12.0	12.0	12.0	13.0	14.0	14.0	14.0	14.0
	0.10	0.0	0.0	2.0	2.0	3.0	4.0	6.0	10.0	12.0	12.0	12.0	13.0	14.0	14.0	14.0	14.0
	0.08	0.0	0.0	2.0	2.0	3.0	4.0	6.0	10.0	12.0	12.0	12.0	13.0	14.0	14.0	14.0	14.0
	0.04	0.0	0.0	2.0	2.0	3.0	4.0	6.0	10.0	12.0	12.0	12.0	13.0	14.0	14.0	14.0	14.0
		400	600	800	1200	1400	1600	1800	2200	2800	3200	3600	4000	4400	4800	5200	6400

RPM [RPM]

Injector Phasing

Injector Phasing is quite important to the function of a direct injection engine. If you move the phasing too far the engine will effectively stop running. All Terminator X wizard cals have an injector phasing table configured to work with stock engines.

NOTE: The auto calculation feature of the injector end angle table is disabled with direct injection.

File Save Toolbox Offline Help Help ? Datalog

SYSTEM PARAMETERS

ECU Configuration

Engine Parameters

Ignition Parameters

Dwell Time

Sensor Scaling/Warnings +

Basic I/O +

Closed Loop/Learn +

Variable Cam Timing

DI Target Fuel Pressure

Injector Phasing

Individual Cylinder

Inputs/Outputs

INJECTOR AUTO-PHASING

	OPEN	CLOSE	DURATION
Cam Intake	0.0° BTDC	0.0° ABDC	180.0°
Cam Exhaust	0.0° BBDC	0.0° ATDC	180.0°
Cam Advance/Retard	0.0°	(-) Retard (+) Advance	Lobe Separation Angle: 90.0°
Injector Placement	0.0 inches		Overlap: 0.0°
Injector Phase Offset	0.0°		Intake Centerline (Abs): 90.0° Intake Centerline (EFI): -90.0°

Graph
Recalculate

Injector End Angle (°)

	500	1000	1500	2000	2500	3000	3500	4000	4500	5000	5500	6000	6500	7000	7500	8000
105	-114.1	-124.7	-97.0	-107.0	-102.0	-111.4	-109.0	-89.9	-111.3	-126.1	-136.8	-126.3	-139.0	-152.1	-165.5	-179.2
100	-111.4	-118.9	-89.6	-107.0	-126.5	-103.6	-102.6	-101.0	-103.3	-115.4	-125.9	-117.5	-131.8	-146.8	-162.4	-178.7
95	-108.9	-114.1	-90.7	-107.8	-117.8	-111.5	-118.9	-108.4	-103.8	-108.5	-116.0	-108.6	-122.3	-137.2	-152.8	-169.2
90	-106.3	-109.9	-97.0	-98.5	-106.7	-128.9	-132.0	-110.3	-104.9	-105.6	-110.1	-103.8	-117.1	-133.0	-149.5	-167.0
84	-105.0	-105.0	-101.7	-103.6	-115.5	-123.0	-129.2	-110.8	-106.0	-106.4	-109.1	-105.6	-118.0	-132.8	-148.1	-164.4
79	-107.2	-107.2	-100.7	-125.5	-131.1	-129.0	-108.1	-104.9	-107.2	-106.8	-109.9	-107.5	-118.7	-132.8	-148.3	-164.3
74	-112.7	-112.7	-116.6	-134.8	-136.9	-133.6	-96.8	-92.9	-98.7	-105.3	-110.0	-106.3	-116.6	-128.9	-142.5	-157.1
69	-115.5	-115.5	-125.6	-136.0	-139.1	-139.8	-94.4	-78.3	-85.1	-93.3	-101.5	-100.0	-106.9	-116.6	-127.4	-139.0
64	-119.2	-119.2	-129.8	-137.4	-135.4	-143.6	-101.2	-75.1	-73.8	-79.0	-89.1	-97.4	-103.5	-111.7	-121.0	-130.8
59	-122.9	-122.9	-133.9	-138.5	-136.4	-143.2	-112.3	-82.3	-80.0	-85.3	-86.0	-86.9	-93.4	-100.8	-108.7	-117.0
54	-126.6	-126.6	-138.1	-142.7	-130.0	-139.9	-123.3	-119.2	-107.3	-104.2	-100.7	-99.8	-98.0	-104.4	-110.2	-117.1
49	-130.0	-130.0	-142.0	-147.0	-130.0	-139.8	-136.9	-137.8	-131.7	-127.0	-117.8	-105.2	-106.9	-112.8	-117.0	-121.3
44	-130.0	-130.0	-142.0	-147.0	-130.0	-140.0	-132.5	-132.0	-126.8	-122.3	-116.5	-101.9	-107.1	-111.8	-115.7	-119.4
39	-130.0	-130.0	-142.0	-147.0	-130.0	-140.0	-130.0	-127.9	-122.2	-116.5	-109.8	-94.1	-97.7	-101.1	-104.8	-108.6
34	-130.0	-130.0	-142.0	-147.0	-130.0	-140.0	-130.0	-125.0	-118.2	-111.6	-103.8	-86.7	-88.5	-90.4	-92.4	-94.8
3	-130.0	-130.0	-142.0	-147.0	-130.0	-140.0	-130.0	-125.0	-115.0	-108.0	-98.8	-80.0	-80.0	-80.0	-80.0	-80.0

Engine RPM

(+) A Positive degree value indicates the fuel injection event will end after BDC of the intake stroke.
 (0) A Zero degree value indicates the fuel injection event will end at BDC of the intake stroke.
 (-) A Negative degree value indicates the fuel injection event will end before BDC of the intake stroke.

Inputs/Outputs

Outputs:

Output #4 is preconfigured in the wiring harness to control the 2-stage oil pump on Gen V engines. If left off the oil pump will default to the high oil pressure state. Turning the output on will lower the oil pressure.

Inputs:

There is a large amount of I/O available from the GDI Controller. There are 4 main categories: Injectors, VVT, Pump, and Diagnostics. The categories and their respective parameters are described in detail below.

Note: If you use the Terminator X Handheld wizard to create a calibration the parameters with a * before their name will automatically be added to the calibration on inputs 21-30.

Injectors:

- * Injector PW 1-8: These 8 parameters are the delivered pulse width to each injector after all modifiers have been applied such as pressure compensation and dead times.
- * Injector Faults 1234 and 5678 – Used for engineering purposes, this should always read 0. If it does not read 0 please Contact Holley Technical Service Dept.

VVT:

- Calculated Oil Temp: The calculated engine oil temperature from the GDI controller
- Desired Cam Position: This is the target cam position the GDI controller is trying to maintain after all modifiers have been applied. **Note:** the GDI desired cam position may not always match the Terminator X desired cam position, this is normal.
- * Actual Cam Position: The actual position of the cam as reported by the GDI Controller
- Solenoid Duty cycle: The calculated duty cycle of the VVT solenoid
- Solenoid Current: The amperage reading of the VVT Solenoid circuit

Pump:

- * Actual Fuel Rail Pressure: This is the rail pressure as measured by the GDI controller
- * Faults: Used for engineering purposes, this should always read 0. If it does not read 0 please Contact Holley Technical Service Dept.
-
- * Start Angle: This is how many degrees before the peak of the fuel pump lobe that the high pressure pump solenoid is activated.
- Duration: This is how long, in degrees, the high pressure fuel pump solenoid is activated
- * PID Output: This is the offset to the start angle to correct for error in the actual vs desired fuel pressure.
- CC/Stroke: This is the amount of fuel in CC per lobe stroke of the high pressure fuel pump.

Diagnostics

- * Cam Sync Status : Displays the current cam sensor syncing status based on the table below

0	SEEK_STALL
1	TOOTH_DETECTED
2	HALF_SYNC
3	FULL_SYNC

- * Crank Sync Status: Displays the current crank sensor syncing status based on the table below

0	SEEK_STALL
1	TOOTH_DETECTED
2	HALF_SYNC
3	FULL_SYNC

- Crank Sync Count: Displays the current crank sensor status based on the table below


1	FIRST HALF CRANK SYNC
2	SECOND HALF CRANK SYNC

- Reserved 1-5: Used for engineering purposes, this should always read 0. If it does not read 0 please Contact Holley Technical Service Dept.
- Boost Converter Voltage: This is the voltage being delivered to the injectors.
- Boost Converter Faults: Used for engineering purposes, this should always read 0. If it does not read 0 please Contact Holley Technical Service Dept.
- Boost Converter MCU Faults: Used for engineering purposes, this should always read 0. If it does not read 0 please Contact Holley Technical Service Dept.
- Comms Faults: Used for engineering purposes, this should always read 0. If it does not read 0 please Contact Holley Technical Service Dept.
- PCB Temp: Internal temperature in Celsius of the GDI Controller
- 8V VCC: Actual voltage from the 8volt regulator
- 3.3V VCC: Actual voltage from the 3.3 volt regulator
- 5V VCC: Actual voltage from the 5 volt regulator

LED Diagnostic Functions

<u>LED #</u>	<u>FUNCTIONS</u>	<u>Color</u>	<u>Definition</u>
1	Heartbeat	Green - flashing 1 sec on / off	ECU is Powered
2	Sync Status	Green	Engine is running and crank and cam sensor are working properly
		Blue	No RPM detected
		Red - flashing 1 sec on / off	Error with crank or cam sensor
3	VVT	Green	VVT working normally
		Red	VVT Error detected resets with key cycle
			Cam was not able to meet target position
4	Pump Control	Green	High Pressure pump is functioning normally
		Red	Error with high pressure pump Resets with key cycle
5	DI injectors	Green	DI Injectors functioning normally
		Red	DI Injector error resets with key cycle
			Short/open circuit detected
			Overlapping injection event
6	Off/Undefined		Future
7	Off/Undefined		Future
8	Off/Undefined		Future

271R1251A





DESCRIPTION	COLOR	WIRE GAUGE	PN#
COIL IN	YELLOW	20 ga	A1
FUEL PUMP RELAY OUT (CIDA MARK)	RED	20 ga IF RELAY TRIGGER	A2
INPUT #2 (FS2H6)	WHITE/RED	20 ga	A3
INPUT #4 (F, E, S)	WHITE/GREEN	20 ga	A4
TPS SIGNAL	GREEN	20 ga	A5
IGNITION OUTPUT	WHITE	18 ga	A6
MBI_COMP#2	TAN (SEE NOTE 3)	20 ga	A7
MBI_SHIELD	SHIELD (SEE NOTE 3)	20 ga	A8
MBI_HTR	YELLOW (SEE NOTE 3)	18 ga	A9
SWITCHED +12V IN	RED/WHITE	18 ga	A10
MAT INPUT	BLUE	20 ga	A11
INPUT #1 (FS2H6)	WHITE/RED	20 ga	A12
INPUT #3 (F, E, S)	WHITE/BLACK	20 ga	A13
IPU GROUND	SHIELD	20 ga	A14
DGI 1A	WHITE/BLACK	20 ga	A15
MBI_COMP#1	BROWN (SEE NOTE 3)	20 ga	A16
MBI_VS+/IP+	BLACK (SEE NOTE 3)	20 ga	A17
SENSOR GROUND OUT	BLACK/WHITE	20 ga	A18
COOLANT TEMP IN	BROWN	20 ga	A19
OIL PRESSURE	GREY	20 ga	A20
KNOCK #2 IN	BEIGE/RED	20 ga	A21
CAM INPUT (DGI & IPU)	PURPLE	20 ga	A22
MAP SENSOR SIGNAL	RED/BLACK	20 ga	A23
CAN LO	ORANGE	20 ga	A24
MBI_VS+	RED (SEE NOTE 3)	20 ga	A25
SENSOR +5V REF OUT	ORANGE	20 ga	A26
BYPASS OUT	BEIGE/BLACK	20 ga	A27
TACHOMETER	BLUE/WHITE	20 ga	A28
KNOCK #1 INPUT	BEIGE/BLACK	20 ga	A29
CRANK INPUT (DGI & IPU)	PURPLE	20 ga	A30
FUEL PRESSURE	PURPLE	20 ga	A31
CAN HI	ORANGE/BLACK	20 ga	A32
MBI_IP+	WHITE (SEE NOTE 3)	20 ga	A33
MBI_HTR+	ORANGE (SEE NOTE 3)	18 ga	A34

GAUGE	COLOR	PN#
20 ga	ORANGE/BLACK	A 327
20 ga	ORANGE	C 427
20 ga	PURPLE	C 427
20 ga	PURPLE/WHITE	C 427
20 ga	PURPLE/WHITE	F 1094 G
20 ga	RED/WHITE	F 1094 G
---	---	G 4110 C
---	---	H 4110 C
---	---	I 4110 C
---	---	J 4110 C
---	---	K 4110 C
---	---	L 4110 C
---	---	M 4110 C
---	---	N 4110 C
---	---	P 4110 C

DESCRIPTION	COLOR	WIRE GAUGE	PN#
IAC A LO	PURPLE/BLUE	20 ga	B1
IAC A HI	PURPLE/YELLOW	20 ga	B2
PMW #4 OUT (HG)	GREY/GREEN	20 ga	B3
INJECTOR F	GREEN	20 ga	B4
INJECTOR E	ORANGE	20 ga	B5
INJECTOR H	BLUE	20 ga	B6
INJECTOR C	PINK	20 ga	B7
IAC B LO	PURPLE/WHITE	20 ga	B8
IAC B HI	PURPLE/BLACK	20 ga	B9
PMW #3 OUT (HG)	GREY/BLACK	20 ga	B10
PMW #2 OUT (HG)	GREY/RED	20 ga	B11
PMW #1 OUT (HG)	GREY/YELLOW	20 ga	B12
INJECTOR D	PURPLE	20 ga	B13
EST GROUND OUT	BLACK/YELLOW	20 ga	B14
EST B	GREEN/WHITE	20 ga	B15
EST D	ORANGE/WHITE	20 ga	B16
EST F	BLUE/WHITE	20 ga	B17
EST H	PINK/WHITE	20 ga	B18
INJECTOR A	GREY	20 ga	B19
EST 12V OUT	RED/YELLOW	20 ga	B20
EST A	YELLOW/WHITE	20 ga	B21
EST C	GREY/WHITE	20 ga	B22
EST E	LIGHT BLUE/WHITE	20 ga	B23
EST G	LIGHT GREEN/WHITE	20 ga	B24
INJECTOR C	BEIGE	20 ga	B25
INJECTOR B	WHITE	20 ga	B26

271R1251A





271R1265A

