

INTERCE Interceptor **Interceptor Controller** Accelerator Controller MAP **Harness** MAP Connector Sensor (3-Pin) Connector (3-Pin) **Intake Air Temp Sensor Connector** (2-Pin) Cam Cam Harness **Intake Air Temp** Sensor Pèdal Connector **Harness Connector** Pedal Connector Harness (4-Pin) Sensor (2-Pin) (4-Pin) Connector Connector Step-By-Step

For 2011-2013 5.7 Hemi Car & 6.4 Hemi SUV SRT8 - (5.7 Part #705001) (6.4 Part #705005)

Hypertech's new product, the Interceptor, is a smart technology design that works with today's generation of complex engine computers. The Interceptor easily mounts under the hood of a vehicle and plugs into the factory connectors to constantly monitor the vehicle's functions. It then automatically recalculates the factory's computer performance calibrations with legendary Hypertech Power Tuning. This means more horsepower and torque, quicker acceleration, better driveability, and improved MPG.

Installation Instructions

The Interceptor Controller easily installs under the hood in about fifteen (15) minutes. The Interceptor Accelerator Pedal Controller installs in the vehicle's interior on the driver's side above the accelerator pedal in about (15) minutes.

BEFORE installing the Hypertech Interceptor:

Make sure the vehicle engine and ignition is turned OFF prior to beginning the installation.

Tools needed for Interceptor installation:

Flashlight



* NOTE: Sensor locations may vary slightly depending on the application.

Installing the Hypertech Interceptor Controller



Locate fuse box in the engine compartment on the passenger side. Press the locking tabs to disengage fuse box and lift up to expose empty compartment. Locking tabs may vary slightly from those shown above.




Place Interceptor Controller on its side in the compartment. Then re-install the fuse box back to its original location.

Before proceeding to the next three (3) installation sections, lay out the Interceptor harness in the general areas of the sensor locations as shown in the engine compartment photo on page 1.

Connecting the Cam Sensor



Route the Interceptor wire to the cam sensor. Disconnect the factory harness from the cam sensor.



Plug the Interceptor cam sensor connector into the vehicle cam sensor.




Plug the Interceptor harness connector into the factory cam sensor wiring harness connector.

NOTE: Ensure that the Interceptor harness and all connectors are clear from moving and/or rotating parts of the engine as well as any extreme heat sources.

Connecting the MAP Sensor




Lift off the passenger side engine cover.



Route the Interceptor MAP sensor harness under the fuel injector harness to the MAP sensor.



Disconnect the factory connector from the MAP sensor. This connector has a locking clip that must be slid back to unlock. Then, squeeze down the locking tab, and push the connector in slightly (toward sensor) and then remove.



Plug the Interceptor MAP sensor connector into the vehicle MAP sensor.

Connecting the MAP Sensor (Cont'd)



Plug the Interceptor harness connector into the factory MAP wiring harness connector, and push in the locking clip.

NOTE: Ensure that the Interceptor harness and all connectors are clear from moving and/or rotating parts of the engine as well as any extreme heat sources.

Connecting the Intake Air Temp Sensor



Route the Interceptor wire to vehicle intake air temp sensor.



Disconnect the factory harness from the Intake air temp sensor.



Plug the Interceptor intake air temp sensor connector into the vehicle intake air temp sensor.


Connecting the Intake Air Temp Sensor (Cont'd)




Plug the Interceptor harness connector into the factory intake air temp sensor wiring harness connector.

NOTE: Ensure that the Interceptor harness and all connectors are clear from moving and/or rotating parts of the engine as well as any extreme heat sources.

Connecting the Interceptor Accelerator Controller




Using a flashlight, locate the factory accelerator harness connector under the driver's dashboard and above the accelerator pedal. Push the carpeted compartment cover out of the way so you can disconnect the factory harness from the accelerator pedal sensor.



Plug the Interceptor accelerator pedal sensor connector into the factory accelerator pedal sensor.

Connecting the Interceptor Accelerator Controller (Cont'd)



Plug the Interceptor accelerator pedal harness connector into the vehicle's factory accelerator pedal sensor connector.

Tuck the Interceptor accelerator controller behind the carpet and out of the way. You may secure it using a zip tie. Installation is now complete! You are now ready to enjoy more power and performance with the Hypertech Interceptor!