## MSD Dual DIS-4 Harness PN 88813

## **Parts Included:**

## **Additional Parts Required:**

8 - Individual Cylinder Harnesses

4 - Ignition Adapters PN 89121

2 - DIS-4 Ignitions (PN 62152 or High Output PN 62153)

**WARNING:** During installation, disconnect the battery cables. When disconnecting the battery always remove the Negative cable first and install it last.

**Note:** It is recommended that you have the Service Manual and wiring diagram for your vehicle before beginning the installation of the MSD DIS Ignition.

Figure 1 shows the firing order for a Ford Modular motor. This chart contains MSD's recommendations for triggering the Dual DIS-4's versus Firing Order. See Figure 7 for Cylinder Identification.

FIRING ORDER	DIS-4 BOX A OR B	CHANNEL
1	Α	1
3	В	1
7	Α	2
2	В	2
6	Α	3
5	В	3
4	A	4
8	В	4

## **WIRING**

The Adapter has six wires that need to be connected. The chart shows each wire's application. Figure 2 shows how to wire the Adapter to the DIS ignitions.

WIRING		
BLACK	Connects to Ground.	
RED	Connects to 12 volt (Ignition).	
INPUTS		
BROWN/WHITE	Connects to the White wire going to the Coils and ECU.	
BROWN/GREEN	Connects to the Green wire going to the Coils and ECU.	
OUTPUTS		
WHITE	Connects to the White wire going to the MSD DIS Ignition.	
GREEN	Connects to the Green wire going to the MSD DIS Ignition.	

Note: The procedure shown in Figure 2 will be performed twice for each DIS-4 Ignition PN 62152 (or H.O. PN 62153).




Figure 2 Installation to an MSD DIS-4 Ignition.




Figure 3




Figure 4




Figure 5




Figure 6






Figure 7 Cylinder Identification.