
Important: Please read these instructions carefully prior to installation.



Important Information

Maximum carrying capacity: Please refer to your vehicle manufacturers handbook for maximum roof loading. Load must be evenly distributed over the crossbars.

Recommendations:

It is essential that all bolt connections be checked after driving a short distance when you install your crossbars. Bolt connections and screw threads must be checked and lubricated at regular intervals (depending on road conditions, usage, loads and distances travelled). You should also check the crossbars each time they are Make sure to fasten your load securely. Please ensure that all loads are evenly distributed and that the centre of gravity is kept as low as possible.

Rhino-Rack cannot be held responsible for incorrect mounting of the roof rack system or for usage that exceeds vehicle and production tolerances.

Use only non-stretch fastening ropes or straps.


Caution: The handling characteristics of the vehicle changes when you transport a load on the roof. For safety reasons we recommend you exercise extreme care when transporting wind-resistant loads. Special consideration must be taken into account when cornering and braking.


Please remove crossbars when putting vehicle through an automatic car wash.


Load Ratings:

The vehicle manufactures recommended load rating is the maximum permissible load per pair of crossbars including the weight of the cross bars, 5kg (11lbs). When crossbars are to be used in off-road conditions, please build a safety factor of 1.5 into this load limit for off-road use. Although the crossbars are tested and approved to AS1235-2000, Off road conditions can be much more rigorous. However, increasing the number of crossbars does not increase the vehicles maximum permissible roof loading.

























Refer to owner manual for urban road roof

load limits.

? kg/ lbs


When these roof racks are to be used on a vehicle that is driven off sealed roads, the manufacturer maximum roof load rating (to be found in the vehicles User Manual) should be *divided by 1.5*. Do not forget to subtract 5kg/11lbs from your maximum carrying capacity due to the weight of the crossbars and legs.




Refer to owner manual for urban road roof load limits.



Divide load limit by 1.5 for off road.









Parts List

| Item | Component Name | Qty | Part No. |
|------|--------------------------|-----|----------|
| 1 | End Cap | 2 | M002 |
| 2* | Leg | 2 | - |
| 3* | Gutter Mount Strap | 2 | - |
| 4 | Gutter Clamp | 2 | M003 |
| 5 | M6 x 12.5mm Flat Washer | 4 | W003 |
| 6 | M6 Spring Washer | 4 | W004 |
| 7 | M6 x 35mm Torx Screw | 4 | B247 |
| 8 | M10 Channel Nut | 2 | N024 |
| 9 | M10 x 30mm Washer | 2 | W023 |
| 10 | M10 Shake Proof Washer | 2 | W021 |
| 11 | Gutter Mount Rubber Foot | 2 | M053 |
| 12 | M10 x 25mm Bolt | 2 | B071 |
| 13 | T27 Security Torx Key | 1 | H054 |
| 14 | Fitting Instruction | 1 | RR-03 |





Tools Required;

16mm or 5/8" spanner, rubber mallet, security Allen key provided in kit, tape measure.



Fit legs to vehicle gutter. Adjust each leg so the foot sits into the corner of the gutter.






Note: M150 Leg shown.



Position the legs parallel across the vehicle.


Measure from same point each side of the vehicle.


Rotate the clamp underneath roof gutter lip. The clamp must be fully located into the corner of the gutter lip. Finger tighten clamp screws.




4 Place crossbars onto legs. Push the leg attachment bolt up and turn so the channel nut is fully located across the inside of the bar. Finger tighten M10 bolt at this stage.

Channel nut must be properly located across the bar when tight. Note: M150 Leg shown.







Note: M150 Leg shown.

