


Universal Backbone Fitting Instructions RUMB1 & RUMB2

Important:

- 1. Check the Rhino-Rack website to ensure you have the latest issue of these instructions.
- 2. Please refer to your fitting instruction to ensure that the roof racks are installed in the correct locations.
- 3. Check the contents of kit before commencing fitment and report any discrepancies.
- 4. Place these instructions in the vehicle's glove box after installation is complete.
- 5. These instructions must be followed for warranty to be upheld.

Fit Time: 1 hour



Carrying Capacity

Check the website, the canopy/topper manufacturer's roof load capacity and the vehicle owners hand book for your vehicle's maximum carrying capacity. Always use the lowest value. Load must be evenly distributed over the system.





Cargo Load Lim

Total permissible weight allowed on top, and attached to roof racks whilst the vehicle is in motion. System eight

Total weight of oof rack system. (Crossbars, Backbone, Platform)



Max System Load C

Please ensure y**ou u** ehicle manufacturer's maximum oof allowance if it is ow**er th** figure list**ed** in the **ting** ch



Vehicle Manufacturer's Load Limit

Total permissible weight attached to the roof of the car. This is inclusive of the weight of the roof rack system.

Warning

- Check part number or kit is correct for use with your vehicle.
- Do not attempt to fit the rack system to your vehicle unless you fully understand th ting instructions. Please direct any questions regarding fitting to the dealer from where the roof racks were pu chased.
- Although the system is tested to ISO 11154, off-road conditions can be muc driven path that does not contain a surface protection layer (tar/bitumen).
- Roof racks must be removed when vehicle is put through an automatic ar ash.
- With utility vehicles, the cabin and the canopy move independently. Roof acks an ehicle can be damaged if the item transported is rigidly fixed at points on both the cabin and canopy. Instead, ri y fi o either the cabin roofracks or the canopy roof racks.
- Always ensure you fasten your load securely.
- Use only non-stretch fastening ropes or straps to attach cargo to your oad.

In service maintenance checks

- All bolt connections should be checked after driving a short distance when ou first install your roof racks.
- All bolted connections should be checked again at regular intervals (weekly is recommended, depending on road conditions, usage, loads and distances travelled).
- All bolted connections should be checked each time they are re-fitted.
- Off-road conditions are more rigorous. Check all bolted connections and our load more regularly.
- Ensure that your vehicle manufacturer's GVM, and gross axle weights are not xceeded (refer to vehicle owner's manual).


Torque Settings

Unless stated otherwise in these instructions, all fasteners should be set to the following torque settings: M6: 4-5Nm (3-4lbs/ft), M8: 8-10Nm (6-7.5lbs/ft) M10: 16-18Nm (12-13lbs/ft).


Note for Dealers and Fitters

It is your responsibility to ensure these fitting instructions are given to the end user or client. These instructions remain the property of Rhino-Rack Australia Pty. Ltd. and may not be used or changed for any other purpose than intended.


RUMB1 Parts List



RUMB2 Parts List



T10 - Vaccum



RUMB1 & RUMB2 Backbone Instructions

