
ROADMASTER

ĸ

MOUNTING BRACKET KIT KIT# **523178-5**

06/18/14

INSTALLATION INSTRUCTIONS



ITEM	QTY	DESCRIPTION	PART #
1	4	1/2" x 3 1/2" BOLT	350103-00
2	2	1/2" x 4 1/2" BOLT	350106-00
3	6	1/2" FLAT WASHER	350308-00
4	6	1/2" LOCK WASHER	350309-00
5	6	1/2" HEX NUT	350258-00
6	2	#10 x 3/4" SELF DRILLING SCREW	350247-35
7	1	WIRE PLUG PLATE	A-003801
8	1	DRIVER SIDE ARM	C-002383A
		PASSENGER SIDE ARM	
10	1	MAIN RECEIVER	C-002717



MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS

KIT# 523178-5 06/18/14

his is one of our EZ5 Twistlock series brackets, which allows the visible front portion of the bracket to be easily removed from the front of the vehicle (Fig.A and Fig.B). The bracket consists of a main receiver brace, two removable front braces, and a hardware pack.

The main receiver brace mounts to the bumper core and frame rails. The removable front braces install in the main receiver brace.

Before starting the installation, lay out the kit components in order, as they will be used. This will give you a visual idea of how the components work, and will also confirm that everything is present and accounted for.





IMPORTANT: All brackets must be assembled with all the bolts left loose for final adjustment and positioning (before tightening) unless otherwise instructed. All bolts *must* be torqued for proper strength. If more than one bolt is used per fastening point, the diagram may only show one.

> Use flat washers over all slotted holes · Use lock washers on all fasteners

ROADMASTER Limited Warranty, including One-Year Conditional Warranty Text and Product Registration Card, in Carton.



Failure to follow these instructions WARNING can result in property damage, personal injury or even death.

- · Installation of most mounting brackets requires moderate mechanical aptitude and skills. We strongly recommend professional installation by an experienced installer.
- The installer must read the instructions and use all bolts and parts supplied. Failure to do so could result in loss of the towed vehicle.
- Use Loctite® Red on all bolts used for mounting this bracket.
- Every 3,000 miles, the owner must inspect the fasteners for proper torque, according to the bolt torque requirements chart on the last page of these instructions. The owner must also inspect all mounts and brackets for cracks or other signs of fatigue every 3,000 miles. Failure to do so could result in loss of the towed vehicle.
- The owner must check the vehicle manufacturer's instructions for the proper procedure(s) to prepare the vehicle for towing. Some vehicles must be equipped with a transmission lube pump, an axle disconnect, driveline disconnect or free-wheeling hubs before they can be towed. Failure to properly equip the vehicle will cause severe damage to the transmission.
- If running changes were made by the vehicle manufacturer after this bracket was designed, some bolts or other fasteners in the hardware pack may no longer be the correct size. It is the installer's responsibility to verify that the bracket is securely fastened to the vehicle and fitted with the correct hardware to account for these changes. Failure to securely fasten the bracket could result in loss of the towed vehicle.
- · If the towed vehicle has been in an accident, it must be properly repaired before attaching the bracket. Do not install the bracket if any structural frame damage is found. Failure to repair the damage could result in the loss of the towed vehicle.

- · Roadmaster manufactures many styles of brackets. If your bracket has removable arms, they must be removed before driving the vehicle, unless the arms can be pinned or padlocked in place. If not secured, the arms could vibrate out, resulting in non-warranty damage or personal injury.
- Some motorhome chassis have such a tight turning radius that you can damage your motorhome, towed vehicle, tow bar or bracket while turning sharply. Before getting on the road, test your turning radius in an empty parking lot. Turning too sharply could result in non-warranty damage to towing system, motorhome and/or towed vehicle.
- Do not back up with the towed vehicle attached or non-warranty damage will occur to your towing system, motorhome and/or towed
- The safety cables must connect the towing vehicle to the towed vehicle frame to frame, with the cables crossed, with enough slack for sharp turns. Refer to the cable instructions for proper routing. Failure to leave enough slack in the safety cables, or failure to connect the safety cables frame to frame, will result in the loss of the towed vehicle.
- This bracket is designed for use with ROADMASTER tow bars and ROADMASTER adaptors only. Using this bracket with other brands, without an approved ROADMASTER adaptor, may result in nonwarranty damage or injury.
- Do not use this document for custom fabrication, as it may not show all parts or structural components. Custom fabrication or an attempt to copy this bracket design could result in loss of the towed vehicle.
- Upon final installation, the installer must inspect the bracket to ensure adequate clearance, particularly around hoses, air conditioner lines, radiators, etc., or non-warranty damage to the towed vehicle will result.
- This bracket is only warranteed for the original installation. Installing a used bracket on another vehicle is not recommended and will void the warranty.




MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS





- 1. *Important:* please use all supplied bolts and parts and read all instructions carefully before beginning this installation. The majority of questions you may have can be answered within the text, and proper installation will ensure safe and secure travel. *Note: this bracket will not fit models with Active Shutters.* Now, begin the installation by removing eight T20 Torx screws attaching the top of the fascia to the core support (Fig.C).
- 2. On each side, remove three T15 Torx screws attaching the fascia to the fender liner and one 7mm (head) screw attaching the fascia to the fender (Fig.D). *Note:* the arrow denotes the approximate location of the 7mm (head) screw behind the flap.





- 3. On each side, remove five 7mm (head) screws attaching the fender liner to the fascia and the fascia to the radiator (Fig.E).
- 4. Remove four plastic fasteners attaching the fascia to the subframe (Fig.F).
- 5. Pull out on the corners of the fascia and up on the top of the fascia to remove it (Fig.G). Disconnect the fog lights and ambient temperature sensor.






MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS

KIT# 523178-5 06/18/14





- 6. From the bottom of the driver's side air deflector, disconnect the ambient temperature sensor wiring loom. On each side, remove the air deflectors by removing three plastic fasteners (Fig.H). *Note:* they will not be replaced. Retain the air deflectors and their plastic fasteners for replacement in case the bracket is ever removed from the vehicle.
- 7. On each side, remove four 7mm (head) screws attaching the headlight to the unibody and set aside for now. *Note:* the passenger side has five 7mm (head) screws (Fig.I).
- 8. Remove three plastic fasteners attaching the air intake to the unibody and set it aside (Fig.J).





- 9. Place the main receiver brace under and around the bumper core and, ensuring that it is flush with the face and underside of the bumper core, clamp it in place (Fig.K).
- 10. On each side, using the side mounting point of the main receiver brace as a template, and ensuring that the drill is level, drill straight through the entire frame rail (Fig.L). *Note:* use a proper-length drill bit and caution to avoid damaging engine components.





MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS


KIT# 523178-5 06/18/14






- 11. On each side, bolt through the hole you drilled in the previous step using the supplied $\frac{1}{2}$ " x 4½" bolt and finish with a $\frac{1}{2}$ " flat washer, lock washer and nut (Fig.M). *Note:* ensure proper alignment, as the bolts will receive Loctite® Red and will be torqued at the end of these instructions.
- 12. On each side, using the two front mounting points of the main receiver brace as templates, and ensuring that the drill is level, drill through the front of the bumper core (Fig.N). *Note:* use a proper-sized drill bit and caution to avoid damaging engine components.





- 13. On each side, bolt through the holes you drilled in the previous step using the supplied $\frac{1}{2}$ " x $3\frac{1}{2}$ " bolts and finish with $\frac{1}{2}$ " flat washers, lock washers and nuts (Fig.M).
- 14. Tighten all bolts to the bolt torque requirements found at the end of these instructions. *Note:* use Loctite® Red on all nuts and bolts.
- 15. Remove the foam shock absorption pad from the back of the fascia by releasing the two clips (Fig.P). *Note:* it will not be replaced. Retain the foam shock absorption pad for replacement in case the bracket is ever removed from the vehicle.
- 16. Reverse steps 7 and 8 to reinstall the headlights and air ducting.
- 17. Hold the fascia in place over the main receiver brace and mark it for trimming. Using the yellow lines in Figure Q as a reference, trim the fascia to allow clearance for the main receiver brace.





MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS






- 18. Reinstall the fascia, reversing steps 1 through 5.
- 19. Note: the following four images are for illustration purposes only, as your specific application may be slightly different.

The spring-loaded pin on the removable arm snaps into a notch on the receiver, locking the removable arm into its final towing position. Before inserting each arm into the receiver, verify that the spring is working by ensuring that the spring-loaded pin moves easily back and forth within the barrel when pulled and that it can be pulled flush with the face of the barrel (Fig.R and Fig.S).






20. On each side, insert the removable front bracket arm into the front receiver 90 degrees from its final towing position, depressing the spring-loaded pin against the receiver (Fig.T). Now, twist back 90 degrees until the spring-loaded pin snaps into place in the notch on the receiver, locking the arm into place in its final towing position (Fig.U).


Please note: it is the owner's responsibility to ensure the locking of the pins before towing. Otherwise, failure of the towing system will result.

21. Install the tow bar to the mounting bracket according to the manufacturer's instructions.



MOUNTING BRACKET KIT INSTALLATION INSTRUCTIONS





IMPORTANT!

Safety cables are required by law. When towing, connect safety cables to the safety cable tabs illustrated on the first page and in Figure V. Make certain there is adequate slack in the cables to allow a full turning radius; otherwise, damage will result. If necessary, longer cables or cable extensions are available.

Three options for attaching the wiring plug to the main receiver brace

For six-wire plugs: use the two supplied 3/4" self-tapping screws to attach the electrical plug directly to the rods on the front of the main receiver brace.

For four-wire round plugs: attach to the plug mounting plate and then use the two supplied ¾" self-tapping screws to attach the mounting plate to the rods on the front of the main receiver brace.

For four-wire flat plugs: place the plug through the mounting plug plate, and then secure it using the supplied zip tie on the front of the plug (Fig.W). Use the two supplied ¾" self-tapping screws to attach the mounting plate to the rods on the front of the main receiver brace.

BOLT TORQUE REQUIREMENTS

Note: The torque values represented below are intended as general guidelines. Torque requirements for specific applications may vary. Roadmaster does not warrant this information to be accurate for all applications and disclaims all liability for any claims or damages which may result from its use.

STANDARD BOLTS			METRIC BOLTS			METRIC BOLTS		
Thread Size	Grade	Torque	Thread Size	Grade	Plated / Unplated	Thread Size	Grade	Plated / Unplated
5/16	5	13 ft./lb.	8mm-1.0	8.8	20 ft./lb. 18 ft./lb.	12mm-1.25	8.8	70 ft./lb. 65 ft./lb.
3/8	5	23 ft./lb.	8mm-1.25	8.8	19 ft./lb. 18 ft./lb.	12mm-1.5	8.8	66 ft./lb. 61 ft./lb.
7/16	5	37 ft./lb.	10mm-1.25	8.8	38 ft./lb. 36 ft./lb.	12mm-1.75	8.8	65 ft./lb. 60 ft./lb.
1/2	5	56 ft./lb.	10mm-1.5	8.8	37 ft./lb. 35 ft./lb.	14mm-2.0	8.8	104 ft./lb. 97 ft./lb.
5/8	5	150 ft./lb.						