

**HONDA BALL JOINT**

---

*This part should only be installed by personnel who have the necessary skill, training and tools to do the job correctly and safely. Incorrect installation can result in personal injury, vehicle damage and / or loss of vehicle control.*

---

1. Remove any existing ball joint (if applicable) by first removing the boot retainer, boot, and snap ring from the ball joint. Using a suitable press, press the ball joint out of the control arm.
2. Press in the new ball joint into the control arm, reinstall the snap ring, boot, and boot retainer.

**Note: Unlike the stock ball joint, this ball joint has no alignment marks and can be installed in any direction.**

**Always check for proper clearance between suspension components and other components of the vehicle.**



**Specialty  
Products  
Company**<sup>®</sup>