


INSTRUCTION SHEET

OFF VEHICLE CARBURETOR SERVICE

ZENITH MODEL-Z267L

GENERAL EXPLODED VIEW

THE GENERAL DESIGN AND PARTS SHOWN WILL VARY
TO INDIVIDUAL UNITS COVERED ON THIS INSTRUCTION SHEET.

**DISASSEMBLY**

USE EXPLODED VIEW AS A GUIDE. THE NUMERICAL SEQUENCE MAY GENERALLY BE FOLLOWED TO DISASSEMBLE UNIT FAR ENOUGH TO PERMIT CLEANING AND INSPECTION. NOTE: BEFORE REMOVING THROTTLE VALVE (14) MAKE A SCRIBE MARK ON VALVE AND SURFACE OF FLANGE FOR PROPER REASSEMBLY. SPECIAL TOOL IS USED TO REMOVE AND INSTALL PUMP CHECK VALVE (35).

NOMENCLATURE

REF. NO.	REF. NO.
1. SCREW & LOCKWASHER (4)-BOWL COVER	24. GASKET-PLUG
2. BOWL COVER ASSEMBLY	25. NOZZLE-MAIN
3. VENTURI	26. GASKET-MAIN NOZZLE
4. PIN-FLOAT LEVER	27. NOZZLE-PUMP
5. FLOAT & LEVER ASSEMBLY	28. GASKET-PUMP NOZZLE
6. GASKET-BOWL COVER	29. SCREW & LOCKWASHER (4)-PUMP COVER
7. NEEDLE & SEAT ASSEMBLY	30. COVER-PUMP DIAPHRAGM
8. JET-IDLE	31. SPRING-PUMP DIAPHRAGM
9. NEEDLE-IDLE ADJUSTING	32. DIAPHRAGM-PUMP
10. SPRING-IDLE ADJUSTING NEEDLE	33. VALVE ASSY-POWER
11. FITTING & SCREEN-INLET	34. GASKET-POWER VALVE
12. PLUG (2)-FUEL PASSAGE	35. CHECK VALVE-PUMP INLET
13. SCREW & LOCKWASHER (2)-THROTTLE	36. SPRING-CHOKE RETURN
VALVE	37. SCREW & LOCKWASHER (2)-CHOKE
14. VALVE-THROTTLE	38. VALVE-CHOKE
15. THROTTLE SHAFT & LEVER ASSY.	39. SHAFT & LEVER-CHOKE
16. RETAINER-THROTTLE SHAFT SEAL	40. SCREW & LOCKWASHER (2)-CHOKE
17. SEAL-THROTTLE SHAFT	BRACKET
18. JET-WELL VENT	41. BRACKET ASSY.-CHOKE
19. TUBE-IDLE PASSAGE	42. RETAINER-FELT SEAL
20. PLUG-MAIN JET	43. SEAL (FELT)-CHOKE SHAFT
21. GASKET-MAIN JET PLUG	44. FLOAT BOWL ASSEMBLY
22. JET-MAIN	
23. PLUG-MAIN NOZZLE	

CLEANING

CLEANING MUST BE DONE WITH CARBURETOR DISASSEMBLED. SOAK PARTS LONG ENOUGH TO SOFTEN AND REMOVE ALL FOREIGN MATERIAL. USE A CARBURETOR CLEANING SOLVENT. MAKE CERTAIN THE THROTTLE BORES ARE FREE OF ALL CARBON AND VARNISH DEPOSITS. RINSE OFF IN SUITABLE SOLVENT. BLOW OUT ALL PASSAGES IN CASTINGS WITH COMPRESSED AIR AND CHECK CAREFULLY TO INSURE THOROUGH CLEANING OF OBSCURE AREAS. CAUTION: DO NOT SOAK NON METAL PARTS IN CLEANING SOLVENTS.

REASSEMBLY

REASSEMBLE IN REVERSE ORDER OF DISASSEMBLY. NOTE SPECIAL INSTRUCTIONS.

SPECIAL INSTRUCTIONS

THROTTLE SHAFT SEAL INSTALLATION-INSTALL NEOPRENE SEAL (17) WITH SEALING EDGES TO THE OUTSIDE. COVER WITH FLAT WASHER (16) AND STAKE IN PLACE.

THROTTLE VALVE INSTALLATION-IDLE STOP SCREW BACKED OUT. INSTALL VALVE (14) WITH SCRIBE MARKS ALIGNED. TAP LIGHTLY TO CENTER IN THROTTLE BORE. TIGHTEN SCREWS SECURELY. THROTTLE HELD CLOSED, TURN THROTTLE STOP SCREW IN UNTIL IT JUST CONTACTS STOP PIN, THEN TURN SCREW IN 1 1/2 ADDITIONAL TURNS.

IDELE NEEDLE INSTALLATION-TURN NEEDLE IN LIGHTLY UNTIL SEATED. THEN BACK OUT 1 1/4 TURNS.

FLOAT LEVEL ADJUSTMENT

WITH BOWL COVER INVERTED, MEASURE FROM THE MACHINE SURFACE OF BOWL COVER (NO BASKET) TO TOP OF EACH FLOAT PONTOON. TO ADJUST BEND FLOAT LEVER CLOSE TO FLOAT BODY. NOTE: WHEN VIEWED FROM FREE END, THE FLOAT PONTOONS MUST BE CENTERED AND AT RIGHT ANGLES TO THE MACHINED SURFACE OF BOWL COVER AND MOVE FREELY ON THE FLOAT PIN.

