TIRE INFLATION KIT - P/N 00043 OPERATING INSTRUCTIONS

The VIAIR Tire Inflation Kit is used for airing up tires, and adding compressed air to any inflatable item with a valve stem. The Tire Inflation Kit has a normally closed lever style air chuck at the end of its rubber hose and includes a 30-foot hose and carry bag. After connection to an air source such as an air tank via the quick connect stud preinstalled in the unit, air may be discharged from the gun by simply squeezing the inflation trigger. To check air pressure, simply release the trigger and check the onboard air pressure gauge.

1. Using the Tire Inflation Gun:

Using a 1/4" Quick Coupler, connect the Tire Inflation Gun to an air hose and connect to a tire valve stem or similar inflation collar by securing the folding lever on the Inflation Gun air chuck.

2. Filling Tires and other Inflatable Items:

Squeeze the Inflation Trigger on the Inflation Gun by pressing it towards the handle of the gun. This will allow stored air from the air tank to flow through the gun and through the chuck into your tire or other inflatable.

3. Checking Tire Pressure:

To check tire pressure, release Inflation Trigger on Inflation Gun and allow the needle of the gauge to settle. Tire pressure will be able to be read only when the inflation trigger is released.

4. Storage:

Always store using the included deluxe carry bag to protect the inflation gun & hose.

WARNING:

- Never operate the Digital Tire Inflation Gun at any pressure exceeding 160 PSI.
- Use caution when attached or removing air chuck from valve stems.
- · Always ensure that tire valve stems are tight before inflating tires.
- Never inflate any tire or other inflatable past its rated pressure to avoid explosion, possible injury or death.

<u>WARNING:</u> Not intended for use with regular portable compressors (units meant to be operated with an open ended air chuck). The Tire Inflation Gun is equipped with a close-ended chuck (will hold pressure back).



