



AMERICAN CAR CRAFT INSTRUCTIONS

DIAMOND PLATE FLOOR MATS

Part#041001



INSTALLATION NORMALLY REQUIRES NO TOOLS

- 1.** Slide front seats as far back as they go.
- 2.** Your custom diamond plate mats come to you flat and it will be necessary to form by hand to achieve a perfect fit. Your mats are made of high quality aluminum and will bend very easily. Some mats will have marks on the back that will indicate where you must bend the mat and whether that the bend should be a hard bend or a soft bend. You can use the edge of a table to create the hard bend. The soft bend can be achieved by hand. It may be necessary to place and bend 2 or more times until you are satisfied with the fit. Some floor mats will be pre-formed by the factory.
- 3.** Once you are satisfied with the fit remove the carpet attachment tape covering and insert the mat into position. **NOTE:** Be sure that the mat creates no restriction of the gas, clutch or brake pedals. Repeat this same process for all remaining mats. Most all rear mats require no bending and should fit just right.

Thank you and enjoy your purchase!