



AMERICAN CAR CRAFT INSTRUCTION

C4 Corvette Vent Covers

Part # 022001 patent pending



PARTS INCLUDED:

- 8-Stainless Vents Covers
- 1-Promoter Pack

Your new vent covers come to you with a protective liner that you will remove after installation. This will help produce a nice clean install.

1. Wash your vent areas first with soap and water to remove all dirt and grime. Then scrub the area to be mounted with household isopropyl alcohol to remove any and all wax let dry.
2. You have been provided with a packet of adhesive promoter; once you have completed the preparation in step one then swipe all eight areas to be mounted once with this promoter.
3. You will need to gently form all eight pieces by hand so that they contour to the body shape exactly without forcing. Doing this will ensure a long lasting permanent bond. NOTE: You have 4 drivers side and 4 passenger sides vent covers, be sure to match each cover to the proper side. Once you have achieved a nice contoured fit simply remove the red liner and insert each piece, pressing firmly to set. Do not get wet for 24 hours.

Thank you and enjoy your purchase!