



AMERICAN CAR CRAFT INSTRUCTION

C5 Polished Corvette lambo Door Jam Plates

PART#031020



Installation Instructions

ITEMS NEEDED:
Household Isopropyl Alcohol

PARTS INCLUDED:
Adhesive Promoter
4-Long Pop Rivets

PLEASE NOTE THAT THIS IS A PERMANENT INSTALLATION AND THE NEW DOOR JAM PLATES CANNOT BE REMOVED WITHOUT DAMAGING THEM.

Your new door jam plates come to you with a protective liner that you will remove after installation. This will help produce a nice clean install.

1. Thoroughly clean the surface area first with soap and water then with household isopropyl alcohol.
2. Then swipe the same area with the adhesive promoter (provided). This promoter will guarantee a good permanent bond.

3. Gently pre-bend the plates to fit. **VERY IMPORTANT: The metal is flexible enough to allow you to gently curve it so that the plates fit the door area without forcing it to lay flat. It should hug the door jam as if it was installed before removing the red liner.**
4. When you are satisfied with the fit, then remove the red liner from the attachment tape and firmly press.

IT IS VERY IMPORTANT THAT YOU SLOWLY INSERT THE PLATES INTO PLACE, THE ATTACHMENT TAPE IS VERY RELIABLE AND IT MIGHT BE A GOOD IDEA TO MAKE A COUPLE OF TEST FITS BEFORE PULLING THE RED LINER!

YOU HAVE ONLY ONE SHOT AT THIS SO GO SLOWLY!

5. Pilot a 1/8" hole at the bottom two holes for each side and install the stainless pop rivets provided. This will insure the bottom edge does not come loose and damage your sill.