



## **AMERICAN CAR CRAFT INSTRUCTION**

### **CORVETTE 2-pc MONOGRAMMED VANITY PLATES**

## **PART#031022**



#### **PARTS INCLUDED:**

- 2-Vanity Plates
- 1-Adhesive Promoter Pack

1. Your new vanity plates are designed to fit just above your door sill area on the door jam. In order to install simply wipe this area clean first with soap and water and then with household isopropyl alcohol. Let dry then swipe once with the adhesive promoter pack provided. Then place your new plate into this area and make note of its position be sure that your plate is contoured to the shape of your door jam if not gently form by hand until your plate lays flat against the car. Once you are satisfied with the location remove the red liner from the attachment tape and reposition. Press firmly to set.
2. Repeat this process for the opposite side.

**Thank you and enjoy your new purchase.**

**Note: Care must be taken when cleaning your new plates. It is a good idea to lightly dust your plates with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.**