



AMERICAN CAR CRAFT INSTRUCTION

POLISHED 4 PC EMBLEM INSERTS PART#031026



PARTS INCLUDED:

- 1-4pc Stainless Emblem INSERTS
- 1-Adhesive Promoter Tube

Your emblem bezels are designed to go around your front and rear factory emblem or your convertible waterfall emblem and attach directly to the painted surface.

1. Clean the area around each emblem with household rubbing alcohol to remove any wax and dirt then swipe the area once with the adhesive promoter tube provided.
2. Place each bezel into position to familiarize yourself with each placement before removing the liner. It WILL BE necessary to HAND FORM the bezels to CONFORM to the shape of the car doing this will prevent any possibility of the bezel popping loose or lifting long term.
3. Once they are fitted properly peel the release liner from the back of each bezel and carefully set them nice and evenly around each emblem. Press firmly to set.

DO NOT GET WET FOR 24 HOURS.

Thank you and enjoy your purchase!