



AMERICAN CAR CRAFT INSTRUCTIONS

C5/Z06 Corvette Door Reflector

Part #031044



PARTS INCLUDED:

- 2-Stainless Side Marker Trim
- 2-16" of 1/4" Chrome Trim
- 1-Pack of Adhesive Promoter
- 1-Tube of Adhesive Promoter

Quick installation tip would be to pull out the door reflector and it will make it a lot easier to install it's just a push clip on the bottom of the reflector and 2 tabs on the top. Remove by unclipped the lower clip and slide it out towards the bottom to release the tabs.

1. Thoroughly clean the factory plastic side marker with alcohol to remove any and all wax and dirt. Once this has been done swipe the entire factory lens with the adhesive promoter pack provided (save enough promoter for the opposite side) allow a few second to dry.
2. Before you permanently attach the stainless bezel set it in place to get acquainted with its position. A properly placed bezel will set perfectly centered evenly all around the perimeter of the factory lens. Once you can see just how it sets in place, peel the release liner from the back of your new bezel and carefully set in place. Press firmly along the entire stainless bezel to make sure you have a nice complete bond.
3. The next step will be to install the chrome trim. Apply a single bead of adhesive promoter tube (provided) along the outer edge of the factory lens. Make sure that the end of the chrome trim is nice and square. Pull the red release liner from the back of the trim and set it at the very bottom center of the factory red lens and work the trim around the lens at the same time try to set the trim tightly against the stainless cover. When you reach the start point mark that point by pressing your finger nail into the trim, doing this will give you an excellent indication where to cut the excess. Apply a tiny drop of an instant adhesive to the edge of the trim and then set the two ends together pressing firmly to set the entire length of the trim.

Thank you and enjoy your purchase!