



AMERICAN CAR CRAFT INSTRUCTIONS
C5 CORVETTE SKULL TAILLIGHT COVERS

PART#032044 patent pending



PARTS INCLUDED:

- 4-Stainless Taillight Grilles
- 8-2" Stainless pan head screws
- 8- Little White Button Sockets
- 8- Little Chrome Cap Covers

Your new taillight covers are made to fit directly over the factory light lenses, however it will be necessary to hand form your new covers so that they match closer to the factory contoured shape. It is important to know and understand that the new cover will not just simply

set into place without pre shaping them. It is also important that you understand that these covers are made to the near exact size of the light opening in the bumper and that this opening slightly sets down into a sort of valley. So in order to properly place them it will be necessary to set the pre shaped cover down into the opening and then roll it onto the lenses.

1. Remove all eight factory screws from the taillights. **NOTE:** These screws will not be reused.
2. Carefully place each taillight cover into position. Do this slowly so that you do not scratch your paint. *(If you feel more comfortable you can tape the painted area around your taillights using masking tape before installing your new stainless covers).* **NOTE: The lamps tend to move, so if you use something smaller in diameter than the screws like a “small” Phillips screwdriver to align everything and then hold it in place prior to installing the new screws, it will make getting the screws started properly much easier.**
3. Once your cover or covers are in position place two of the replacement screws (provided) thru the white button sockets (provided) and fasten securely being careful not to over tighten.
4. Snap on chrome screw cap covers (provided).