

AMERICAN CAR CRAFT INSTRUCTIONS

C5 Corvette GM Licensed Rear Bumper Letters Part #032049



PARTS INCLUDED:

1-Set Stainless Rear Bumper Letters 1-Tube of Adhesive Promoter

Introduction: <u>These high quality hand polished stainless steel rear bumper letters</u> are Made in America using only the finest precision cut T-304 stainless and 3M attachment tape for easy installation. Genuine GM Licensed

- 1. Thoroughly clean the painted surface to remove any and all wax, dirt and silicones that may be present using household rubbing alcohol. Once the surface had been successfully cleaned, swipe the area to be mounted with the adhesive promoter provided.
- 2. Place each letter into position to familiarize yourself with each placement before removing the liner. It MAY BE necessary to HAND FORM the letters to CONFORM to the shape of the car doing this will prevent any possibility of the letters popping loose or lifting long term. Remove the red protective liner from the back and place your letter directly to the treated surface and press firmly to set. Clean away any and all excess adhesive promoter with rubbing alcohol to finish the installation.

Do not get wet for 24 hours!

Thank you and enjoy your purchase!