



AMERICAN CAR CRAFT INSTRUCTIONS

DESCRIPTION C5 Radiator Cover Polished End Caps

PART #033059



Parts Included:

2-Stainless End Caps

Introduction: This optional accessory has been designed as the finishing touch for the ACC C5 Radiator Cover. The part will work for both the smooth #033057 and perforated #033058 versions and is easy to install in just a few steps.

Liner Information: Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and or possible scratches during installation.

1. Remove the two ten millimeter bolts securing the factory black plastic radiator support.
2. You will notice that the part will contain a small tab rolled over at the top corner of each part. (driver side & passenger side) This tab has been designed to slip into the top corner of the component radiator cover. If you look closely at this side area towards the front of the car you will notice a small channel. Slip the tab of the part into the channel of the cover and then line up the two holes at the base of the part with the hole you exposed earlier when you removed the factory bolts.
3. Once you have the part correctly inserted and lined up simply remove the protective liner and then reinstall the factory bolts.