



AMERICAN CAR CRAFT INSTRUCTION

C5 Corvette Crossed Flags Alternator Cover

Part# 033084 Patent Pending



ITEMS NEEDED:

9/64 Drill Bit

PARTS INCLUDED:

1-Stainless Alternator Cover
2-1/2" #8 Pan Head Screws
2-Plastic Washers
2-Chrome Caps

1. Place your new cover into position.
2. Align the two holes in the cover with the main alternator bracket ridge. (This is a small area and must be matched up properly.)
3. Mark holes in cover to ridge in bracket using a fine point marker or scribe.
4. Using a 9/64 drill bit, drill marked holes only about 1/4" deep.
5. Place cover back over drilled areas and place screws (provided) through plastic washers then tighten. **BE CAREFUL NOT TO OVER TIGHTEN.** Push chrome caps (provided) onto screws until they snap into place.