



## **AMERICAN CAR CRAFT INSTRUCTIONS**

### **C6 CORVETTE DOORSILLS BRUSHED/POLISHED - PLAIN**

**Part #041013** patent pending



**PLEASE NOTE THAT THIS IS A PERMANENT INSTALLATION AND THE NEW DOORSILLS CANNOT BE REMOVED WITHOUT DAMAGING THE PART. PLEASE NOTE YOUR CAR WILL NOT BE DAMAGED IN ANY WAY.**

**Your new doorsills come to you with a protective liner. DO NOT remove the liner until step 4.**

1. Thoroughly clean the surface first with soap and water then with household isopropyl alcohol.
2. Then swipe the same area with the adhesive promoter (provided). This promoter will guarantee a good permanent bond.
3. When you are satisfied with the fit, remove the red liner from the attachment tape, reposition your new sill and press firmly.

**IT IS VERY IMPORTANT THAT YOU SLOWLY INSERT THE SILLS INTO PLACE. THE ATTACHMENT TAPE IS VERY RELIABLE AND IT MIGHT BE A GOOD IDEA TO MAKE A COUPLE OF TEST FITS BEFORE PULLING THE RED LINER!**

**YOU HAVE ONLY ONE SHOT AT THIS SO GO SLOWLY!**

4. Once in place remove the protective liner. Repeat steps 1-5 for the opposite doorsill.

**Thank you and enjoy your purchase!**