



## **AMERICAN CAR CRAFT INSTRUCTION**

### **C6 Corvette Doorsills**

**Part #041017** patent pending



#### **PARTS INCLUDED:**

- 2-Stainless Doorsills
- 2-Adhesive Promoter

**PLEASE NOTE THAT THIS IS A PERMANENT INSTALLATION AND THE NEW DOORSILLS CANNOT BE REMOVED WITHOUT DAMAGING THE PART. PLEASE NOTE YOUR CAR WILL NOT BE DAMAGED IN ANY WAY.**

Your new doorsills come to you with a protective liner that you will remove after installation. This will help produce a nice clean install.

1. Thoroughly clean the surface area first with soap and water then with household isopropyl alcohol.
2. Then swipe the same area with the adhesive promoter (provided). This promoter will guarantee a good permanent bond.
3. When you are satisfied with the fit, remove the red liner from the attachment tape and firmly press.

**IT IS VERY IMPORTANT THAT YOU SLOWLY INSERT THE SILLS INTO PLACE, KEEPING THE LARGE FLAP AWAY FROM THE CAR. THE ATTACHMENT TAPE IS VERY RELIABLE AND IT MIGHT BE A GOOD IDEA TO MAKE A COUPLE OF TEST FITS BEFORE PULLING THE RED LINER!**

**YOU HAVE ONLY ONE SHOT AT THIS SO GO SLOWLY!**

4. Once in place pull the protective liner off the sills.

**Thank you and enjoy your purchase!**