



AMERICAN CAR CRAFT INSTRUCTIONS
CORVETTE 2-pc MONOGRAMMED VANITY PLATES
PART#041028 Patent Pending



PARTS INCLUDED:

2-Vanity Plates

1-Adhesive Promoter Pack

1. Your new vanity plates are designed to fit just above your door sill area on the door jam. In order to install simply wipe this area clean first with soap and water and then with household isopropyl alcohol. Let dry then swipe once with the adhesive promoter pack provided. Then place your new plate into this area and make note of its position be sure that your plate is contoured to the shape of your door jam if not gently form by hand until your plate lays flat against the car. Once you are satisfied with the location remove the red liner from the attachment tape and reposition. Press firmly to set.
2. Repeat this process for the opposite side.

Thank you and enjoy your purchase!