



AMERICAN CAR CRAFT INSTRUCTIONS

C6 Corvette Brake Pad Covers 4pc Part #042046



PARTS INCLUDED:

4-Brake Pad Covers

1. Jack up your car and place it on a pair of jack stands for safety then remove the wheel.
2. Remove both caliper retaining bolts and remove caliper.
3. Compress the caliper piston slightly to create the clearance for the new brake pad cover.
4. Remove the outer brake pad and apply a small smear of household silicone to the back of your new stainless pad plate and place it over the brake pad.
5. Reposition the pad and reposition brake caliper and tighten **SECURELY!**
6. Follow steps 1- 5 for your 3 remaining wheels.

PLEASE NOTE: These custom pad covers in NO way alter your braking system. American Car Craft and its distributors will not be responsible for any improper installations; such as loose bolts or improper placement that may cause any danger or damage in any way, shape or form. Please follow instructions carefully and be sure to put your brakes back together safely and securely!

Thank you and enjoy your purchase!