



AMERICAN CAR CRAFT INSTRUCTIONS

C6 CORVETTE GRAND SPORT BRUSHED FENDER TRIM PLATES

PART #042083



Parts Included:

2 x Adhesive Promoter Packs

4 x Stainless Trim Plates

4 x Pre cut Molding Strips (optional)

Liner Information: Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and or possible scratches during installation.

Although your panels come to you are shaped it is **absolutely imperative** that you shape the panel further by hand so that they match the vehicle contour perfectly before being permanently attached, doing this will prevent any possibility of the panels popping out of place long term.

1. Thoroughly scrub clean the painted surface with alcohol to remove any and all road grime and dirt. Test that you have achieved this by applying a strip of masking tape to see if the tape sticks well .if it doesn't repeat the procedure until it does. Once you have achieved a nice clean bondable surface apply the adhesive promoter provided in your kit. This chemical is **not** a cleaner but an adhesive accelerator and **must** be used to insure a long term bond. Apply one thin and complete swipe to the painted surface.

2. Before you permanently attach your new parts begin by placing them in position to become acquainted with their placement and to check there overall shape. Tweak the shape and practice placing them into position a couple of times before you remove the liner. The adhesive on the parts is very aggressive and will not allow you to reposition the panels should they make contact in the wrong position. So go slowly and sure.

3. When you are ready peel the red release liner from the back of each section and then carefully set them in place pressing very firmly along there lengths to set the bond. Remove the protective liners to finish the installation.

4. You have been supplied with 4 precut strips of molding that if you choose can be applied to the factory paint that runs along the edges of the stainless plates that you just installed which would cap off the edges of your new plates.