



AMERICAN CAR CRAFT INSTRUCTIONS

C6 CORVETTE Z06 LASER MESH DRIVING LIGHT COVERS BLAKK STEALTH PART#042106



PARTS INCLUDED:

2-Stainless Laser Mesh Driving Light Covers w/attachment tape
1-Adhesive Promoter Packet

1. Clean the surface of your light lens first with household rubbing alcohol to remove any dirt and or waxes. Then swipe the lens area once with the adhesive promoter tube provided.
2. Before permanent installation carefully place the new stainless light cover into position to check the shape of the cover. Make sure the overall shape of the new cover matches the shape of the factory lens exactly. Although the new cover comes to you pre shaped it will be necessary to gently form the cover by hand until you have achieved a nice perfect conformed fit to your factory lens cover without forcing. At this time you will need to make note of just how the cover sits in place making sure it sits nice and centered on the factory lens.

3. Once all preparations have been made and you are clear on just how the stainless cover places on the lens you can now remove the release liner from the back of the lens and carefully place the cover into position pressing firmly to set.
4. Repeat the entire process for the opposite side.

DO NOT GET WET FOR 24 HOURS!

Note: Care must be taken when cleaning your covers. It is a good idea to lightly dust your covers with a clean soft cloth first in order to prevent any particles from scratching them. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

Thank You and Enjoy Your Purchase!