



## **AMERICAN CAR CRAFT INSTRUCTIONS**

### **C7 GM LICENSED STINGRAY FONT CAP COVER SET 5PC**

**PART#053019** patent pending



#### **PARTS INCLUDED:**

- 1-Styrofoam Circle for oil cap
- 3-3/4" Caps
- 1-1/2" Cap
- 1-1" Cap
- 5-Attachment Cookies
- 1-Pack Adhesive Promoter

1. The first step for installation will be to thoroughly scrub the tops of each of the factory caps, the oil/water/washer fluid/brake fluid/power steering and clutch fluid if so equipped. Scrub them with alcohol to remove any surface contaminants then swipe the tops with the adhesive promoter provided.
2. You have been provided with 2" furry hook and loop fastener attachment cookies for each cap. Peel the release liner from the back of each cookie and firmly set them to the top of each factory cap.