



AMERICAN CAR CRAFT INSTRUCTIONS

C7 Corvette GM Licensed “STINGRAY” font Cap Cover Set 6PC

Part #053020 Patent Pending



PARTS INCLUDED:

- 1-Styrofoam Circle for oil cap
- 4-3/4” Chrome Caps
- 1-1/2” Chrome Cap
- 1-1” Chrome Cap
- 1-Pack of Adhesive Promoter

1. The first step for installation will be to thoroughly scrub the tops of each of the factory caps, the oil/water/washer fluid/brake fluid/power steering and clutch fluid if so equipped. Scrub them with alcohol to remove any surface contaminants then swipe the tops with the adhesive promoter provided.
2. You have been provided with 2" furry hook and loop fastener attachment cookies for each cap. Peel the release liner from the back of each cookie and firmly set them to the top of each factory cap.
3. The factory wind shield washer fluid cap will need to be trimmed slightly in order for the new cover to sit nice and centered. To do this, simply snip the finger tab as well as the attachment strap off the cap with a scissor.
4. The set will contain a cap cover that is angled for the oil cap and a thinner cover for the power steering cap. The remaining covers in your kit are for all other factory caps. Simply set them in place.