

## **AMERICAN CAR CRAFT INSTRUCTIONS**

## CAMARO STAINLESS <u>CHOPPED OVAL</u> EXHAUST TRIM RINGS PART #102004



PARTS INCLUDED: 2-Stainless Trim Rings 1-Adhesive Promoter Tube

- 1. You have been provided with two stainless exhaust trim rings. These rings are designed to fit directly to the factory rear valance. Oval in shape their placement will be self evident.
- 2. Thoroughly scrub clean the oval area over each of the two exhaust tip openings with household rubbing alcohol to remove any and all dirt and wax.
- 3. Next swipe the two areas with the adhesive promoter provided. IMPORTANT: Before you permanently stick the new trim rings, place them in position to determine how to shape them so that the contour to the factory valance perfectly. Doing this will prevent lifting long term. Once you are satisfied with the shape and contour of the rings simply peel the red release liner from the back of the rings and then carefully position them in place pressing firmly to set.