



AMERICAN CAR CRAFT INSTRUCTIONS

Camaro Front Hood Grille Scoop

Part #102017



PARTS INCLUDED:

- 1-Stainless Hood Scoop
- 1-19½" of Chrome Trim
- 1-20" of Chrome Trim
- 1-20½" of Chrome Trim
- 1-Pack of Adhesive Promoter

Do not remove liner until installation is complete.

1. Thoroughly clean the area to be mounted with rubbing alcohol to remove any and all wax and dirt. Then swipe the area once with the adhesive promoter provided. Make sure you also clean and swipe the entire black plastic factory grille.
2. The main stainless steel insert comes to you pre-shaped however it WILL be absolutely necessary to further shape the insert by hand to achieve a nice perfect contour to the Camaro's header area. You can do this by setting the piece in place to determine what adjustments may be necessary. Mold the insert between your fingers until it fits perfectly without forcing any part of it to contour to the car. Once this is done simply peel the red release liner from the back of the insert and then carefully set it into position. Press firmly to set. A nicely set insert will sit nice and tight into the two tiny notches of the insert.
3. You have been provided with three lengths of chrome trim. Tuck the smaller one at the bottom insert of the factory grill so that the ends fall just behind the insert's back edge. The next size goes just above that one and then the final one adheres directly to the painted ridge between the top corners of the insert. Peel the protective liner to finish the installation.

Thank you and enjoy your purchase!