



AMERICAN CAR CRAFT INSTRUCTIONS

Camaro Stainless Flame Rear Emblem Trim

Part# 102018 patent pending



PARTS INCLUDED:

1-Stainless Rear Emblem Trim

Your emblem trim is designed to go around your rear factory emblem and attach directly to the painted surface.

1. Clean the area around the rear emblem with household rubbing alcohol to remove any wax and dirt.
2. Place the trim into position to familiarize yourself with the placement before removing the liner. It **WILL BE** necessary to **HAND FORM** the bezel to **CONFORM** to the shape of the car doing this will prevent any possibility of the bezel popping loose or lifting long term.
3. Once it is fitted properly peel the release liner from the back of the bezel and carefully place it around the rear emblem. Press firmly to set.

Thank you and enjoy your purchase!