



AMERICAN CAR CRAFT INSTRUCTIONS

Camaro Exhaust Tips w/ Chopped Oval Trim Rings Part #102027



PARTS INCLUDED:

- 2-Stainless Exhaust Tips
- 4-1/2" Long 3/16th Stainless Rivets
- 2-Stainless Trim Rings
- 1-Adhesive Promoter Tube

These beautiful exhaust tips are made of a high quality 304 stainless steel highly polished to a mirror finish. They are designed to mount to the factory tail pipe and can be permanently installed using common tools.

1. Slip the new tip over the factory tail pipe as far back as it will go or as far back as you would like it. Rotate the tip to your liking and then pilot one of the two far back holes on the under side of the new tip with a 3/16" drill bit.
2. You have been provided with two 1/2" long 3/16th stainless rivets for each tip. Once you have one hole piloted set one of the rivets into the hole and then set it with your rivet tool. Once you have the first rivet installed drill the second hole and then insert and install the second rivet to finish the tip installation. The remaining hole close to the tips end is a weep hole for condensation. Repeat the installation procedure for the remaining tip to finish the installation.

3. You have been provided with two stainless exhaust trim rings. These rings are designed to fit directly to the factory rear valance. Oval in shape their placement will be self evident.
4. Thoroughly scrub clean the oval area over each of the two exhaust tip openings with household rubbing alcohol to remove any and all dirt and wax.
5. Next swipe the two areas with the adhesive promoter provided. **IMPORTANT:** Before you permanently stick the new trim rings, place them in position to determine how to shape them so that the contour to the factory valance perfectly. Doing this will prevent lifting long term. Once you are satisfied with the shape and contour of the rings simply peel the red release liner from the back of the rings and then carefully position them in place pressing firmly to set.

Thank you and enjoy your purchase!