



AMERICAN CAR CRAFT INSTRUCTIONS

CAMARO 2pc BILLET STYLE BACK UP LIGHT COVERS

PART#102030 patent pending



PARTS INCLUDED:

2-Stainless Billet Back Up Lights

1-Adhesive Promoter Tube

- 1. Clean the area to be mounted with household rubbing alcohol to remove any wax and dirt then swipe the area once with the adhesive promoter tube provided.**
- 2. Place each cover into position to familiarize yourself with each placement before permanently attaching.** It MAY BE necessary to HAND FORM the covers to CONFORM to the shape of the car doing this will prevent any possibility of the cover popping loose or lifting long term.
- 3. Once they are fitted properly peel the release liner from the back of each cover and carefully set them nice and evenly to your car. Press firmly to set.**

DO NOT GET WET FOR 24 HOURS!