



## AMERICAN CAR CRAFT INSTRUCTIONS

### Coil Pack Covers Square Polished 24pc Part #103049



#### **PARTS INCLUDED:**

16-124NC Chrome Cap  
8-Coil pack covers

1. Remove all (16) factory coil pack attachment bolts
2. Then remove the protective liners and simply attach all (8) custom coil pack covers using the factory screws. Leave the two far screws of the two rear covers out at this time.
3. Now place the 16 cap provided on the threaded bolts.

When it comes to quality chrome trim and accessories, American Car Craft is the brand you can depend on.