



**AMERICAN CAR CRAFT INSTRUCTION**

## **CHALLENGER FRONT HEADLIGHT BEZELS**

**PART#152001**



**PARTS INCLUDED:**

- 2-Brushed Stainless Bezels
- 1-Adhesive Promoter Pack
- 4-Strips of 5/8" Chrome Molding 22"

These new headlight bezels have been designed to treat both the inside and outside of the factory black plastic light bezel transforming it into an upgraded custom look.

**Your covers come to you with a protective liner. Do not remove liner until installation has been completed.**

1. Thoroughly clean the face as well as the inside lip of the factory black plastic bezel with alcohol to remove dirt and grime. Then swipe the areas once with the adhesive promoter pack provided.

2. You have been provided with four strips of chrome molding. Two of these moldings will be longer than the other two and will be applied to the outer openings of the factory bezel.

3. Take a look up at the top of each whole opening. You will notice that the openings are cut off and flat at the very top. NOTE: The moldings will not cover these areas. Peel a small length of the red release liner from the back of each section of molding and apply it directly to the corner of the opening and apply pressure to set the molding so that it sets nice and flush with the outside edge. Set the molding all the way around to the opposite side and snip off any excess molding with a scissor. Press firmly along the entire length to set. Do this for all four whole openings.

4. Now that you have each of the four holes lined with the chrome molding you can apply the outer bezel. Before you permanently install the bezel place it in position to get acquainted with the proper position. You will notice that the holes in the bezel will slightly overlap the chrome molding and should line up with the outer shape of the factory bezel. Once you have a good idea how the bezel will set in place simply remove the red release liner from the back of the bezel and carefully reset it in place. Be sure to take your time as the adhesive tape is very aggressive and will not allow you to reposition the bezel once it has made contact so go SLOWLY. Repeat the application for the opposite side and remove the protective liners to finish the installation.

**Thank you and enjoy your new purchase!**