



**AMERICAN CAR CRAFT INSTRUCTION**

**CHALLENGER SMOKED PLEXI W/POLISHED TRIM TAILLIGHT INSERTS**

**PART# 152021** patent pending



**PARTS INCLUDED:**

- 3-Smoked Plexiglass Inserts
- 3-Polished Taillight Trim Pieces
- 1-Adhesive Promoter Pack

Your new inserts come to you with a protective liner. DO NOT remove the liner until installation is complete.

This three piece kit has been designed to enhance and upgrade the factory taillight area. Constructed of 304 stainless this kit will look beautiful for years and years without ever dulling or rusting. This is a simple to install kit that will transform your Challenger taillight into a nice custom looking tail end.

1. Thoroughly clean the taillight areas to be mounted with alcohol to remove any and all dirt and or waxes. After this step place a piece of masking tape to see if you have achieved a tack. If so swipe the areas once with the adhesive promoter pack provided.

2. Before you permanently attach any thing practice placing each section in position and make note of their correct placement. Make sure that the factory taillight deck lid section lines up properly with the quarter panel taillight sections. This may require you to adjust the deck lid stops just under the deck lid so that the three areas line up to each other perfectly. This step will insure that the new kit will line up properly and offer the best look.

3. Starting with the larger center section peel the red release liner from the back of the part and then carefully place into the correct position and then press firmly to set. NOTE: Be sure that this section is right side up. If you look closely at this section you will notice that there is a perfectly straight edge. This is the bottom edge and the top edge has a slight arch to it as does the factory taillight.

4. Now that you have correctly placed the center section, the sides are relatively easy. Just make sure they ends that meet the center section line up properly as you stick these two remaining parts into position again press firmly to set. Remove the protective liner.

**DO NOT GET WET FOR 24 HOURS**

**Thank you and enjoy your new purchase!**