



AMERICAN CAR CRAFT INSTRUCTIONS

2008-2015 Charger Cap Cover Sets "RT"

11pc Part #333054



PART INCLUDED:

2-#4277 Chrome Covers

6-#121 Chrome Top Hats

2-Pack of Adhesive Promoter

1-3/4" Chrome Cap for (Water Tank)

1-1/2" Chrome Cap for (Power Steering)

1-#17385 Replacement Oil Cap

1. The first step for installation will be to thoroughly scrub the tops of each of the factory caps you where provide covers for, water tank cap and power steering cap with alcohol to remove any surface contaminants then swipe the area with the adhesive promoter provided.
2. You have been provided with 2" furry hook and loop fastener attachment cookies attached to the caps already. Peel the release liner from the back of each cookie and firmly set them to the top of each factory water tank cap and power steering cap.

SHOCK TOWER COVERS

1. Apply an appropriate amount of clear 100% silicone into each of the covers and set them in place over each bolt nut and around the center shock platform. Allow a few hours to set.

OIL CAP

1. Remove your old factory oil cap and replace it with the new one that you have been provided.

Thank you and enjoy your purchase!