



AMERICAN CAR CRAFT INSTRUCTIONS

1996-2002 VIPER Glove Box Cover Laser Etched with Viper Head Part # 961003



PART INCLUDED:

- 1-Glove Box Cover
- 1-Adhesive Promoter Pack

VERY IMPORTANT! You must follow all the steps as described below. Do not skip any steps.

1. BEFORE you begin you must first prepare the GLOVE BOX area in order to allow the Adhesive to Set! You can do this by scrubbing the entire area first with household Rubbing Alcohol. Your part will not bond permanently without cleaning the surface with alcohol!

Caution: If your glove box has been treated with armor-all or silicone coatings such as wax, installation Will NOT work unless these treatments have been REMOVED. You can check your local auto parts store for a 'WAX and SILICONE REMOVER'. We recommend a "3M-Wax and Silicone Remover).

If your glove box has been treated with Armor-All the household Rubbing Alcohol alone will not remove it. You must use a wax and silicone remover.

NOTE: Some glove boxes have been treated at the dealerships before you purchased the car. So to be extra safe you may want to use the wax and silicone remover just in case.

2. Once this is done use the adhesive promoter (provided in the little plastic packet) to wipe your glove box's entire area to be covered with your new glove box cover. Allow 30 seconds to dry.
3. Before you remove the red liner for permanent attachment place the Glove Box cover into position and check the fit. Your cover comes to you pre-formed but it may be necessary to form (bend very slightly) by hand to insure a nice flat fit without forcing. Make note of its position.
4. Remove the red liner from the taped back and carefully reposition the glove box cover, be sure it is straight. Then press firmly on the cover to set.
5. Let set for 2 hours and then remove protective clear top liner.



Thank You and Enjoy Your Purchase!