



## AMERICAN CAR CRAFT INSTRUCTIONS

---

### 1992-2002 VIPER 3<sup>rd</sup> Brake Light Trim - Polished Part # 962019



**PART INCLUDED:**

- 1-3<sup>rd</sup> Brake Light Trim with Viper script
- 1-Tube Adhesive Promoter

**NOTE:** Your new covers come to you with a clear protective liner. Do not remove liner installation is complete.

1. Clean your Third Brake Light first with soap and water and then with household isopropyl alcohol and let dry.
2. Take your new Third Brake Light Bezel and hold it in the position where it is to be mounted. Do not remove the top clear liner or the bottom red liner. Move the Bezel around until you find the perfect fit. It will be fastened to your stock third brake light lens.
3. Then swipe the area ONLY where you will be placing your new Bezel with the adhesive promoter (packet provided). Once you have carefully applied the adhesive promoter correctly you may begin the installation.
4. Carefully remove the back red liner exposing the sticky tape back. With

two hands hold the Bezel over the area where you are going to mount it. Slowly and carefully let it lightly touch the lens where it is to attach to. Make any minor adjustments needed. Once you are satisfied with the position push on the Bezel all over its surface for a good bond.

5. Peel off the front Clear liner and you are finished. Enjoy!

**DO NOT GET WET FOR 24 HOURS.**

**Thank You and Enjoy Your Purchase!**