



## **AMERICAN CAR CRAFT INSTRUCTIONS**

---

### **C5 2-pc PERFORATED STAINLESS FOG LIGHT GRILLES**

## **PART #032018**

#### **PARTS INCLUDED:**

\_\_\_ 2- Stainless Grilles  
\_\_\_ 2- Adhesive Promoter Packs  
\_\_\_ 2- 12" Lengths 1/2" Black Molding w/  
grain \_\_\_ 2- 32" Lengths 1/4" Chrome  
Molding

1. Scrub the painted surface of the fog light opening closest to the black fog light shroud and the shroud area above the light just past the painted edge with alcohol to remove all dirt and wax. Then swipe the area once with the adhesive promoter provided.
2. You have been provided with a 12" length of black molding. Apply this length to the bottom of the hole at the very edge of the painted surface. Press firmly to set making sure the trim is attached to the painted surface and NOT to the black fog light shroud.
3. With the trim in place and all the mountable areas cleaned and prepped you may begin installation by removing the red release liner from the attachment tape at both areas on the grille. Then carefully place first the bottom of the appropriate grille into the hole setting it against the black trim as you slide the top of the grille past the painted surface directly onto the black fog light shroud. Press firmly to set both the top and the bottom of the grille.
4. You have been provided with a 32" length of 1/4" chrome trim. To install this trim place it at the top center of the hole directly to the paint. NOTE: The trim will not touch the grille at the top area. Simply follow the painted edge all the way around to the grille making sure that the trim presses firmly against the grille at the side and bottom areas as you attach it to the paint. Work your way to your starting point and cut away any excess trim into a nice tight butt seam.

5. Repeat process for the opposite side.



When it comes to quality chrome trim and accessories, American Car Craft is the brand you can depend on.