



AMERICAN CAR CRAFT INSTRUCTIONS

C5 Corvette Rear Tag Plate Perforated Part#32020



PARTS INCLUDED:

- 1-Perforated Tag Plate
- 1-Stainless Tag Frame
- 4-1/4" #12 Screw
- 4-Chrome Screw Covers

1. Remove screws from stock license frame.
2. Install new Tag plate and Frame.
3. Snap Chrome Screw Covers over screw head.

Thank you and enjoy your purchase!