



AMERICAN CAR CRAFT INSTRUCTIONS

C5 Corvette GM Licensed Rear Tag Frame

PART #032050



PARTS INCLUDED:

- 1-Chrome/Stainless/Carbon Fiber Rear Tag Frame
- 2-#12x1-1/2" Phillips Pan Head Screws
- 2-White Sockets
- 2-Large Chrome Screw Covers

1. Remove screws from stock license frame.
2. Install new Tag Frame and install new hardware.
3. Snap Chrome Screw Covers over screw head.

Thank you and enjoy your purchase!