



AMERICAN CAR CRAFT INSTRUCTION

C5 CORVETTE 2-pc LICENSED FUEL RAIL COVERS

PART# 033038patent pending

- ___ 2-Stainless Fuel Rail Covers
- ___ 1-Angle Chrome Cover w/Hook and Loop Fastener
- ___ 1-Adhesive Promoter Pack
- ___ 1-Stainless Fuel Line Cover w/tape

Your new covers come to you with a protective liner. Do not remove liner until installation is complete.

1. Your new fuel rail covers have been designed to snap over the existing factory covers. Simply remove the stock fuel rail covers and snap the new covers over top of them. Using a small rubber mallet tap the two small tabs over to lock in position and reinstall your covers.
2. Once you have successfully reinstalled your covers remove the protective liner.
3. You have been supplied with a small stainless fuel line cover to be placed over the fuel line via attachment putty on the C6 covers 05-07 ONLY. On the C5 covers the stainless fuel line cover just peels and sticks over the fuel line. Simply form and press in place.
4. You have been provided with a decorative chrome oil cap cover. Simply clean the top of the factory oil cap with household rubbing alcohol to remove dirt and road grime then swipe it once with the adhesive promoter pack provided. Remove the hook and loop fastener attachment cookie half from the underside of the cap cover and peel the release liner then place it on top of the factory oil

cap and press firmly to set. Then simply position the new chrome cover in place.

Note: Care must be taken when cleaning your covers. It is a good idea to lightly dust your covers with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.