



AMERICAN CAR CRAFT INSTRUCTION

CORVETTE C-5 ALTERNATOR COVER

PART# 033041/033051 patent pending

INSTALLATION INSTRUCTIONS

Items
Needed: 9/64
Drill Bit

Parts Included:
2-Screws
2-Plastic Washers
2-Chrome Caps
Stainless Alternator

1. Place your new cover into position.
2. Align the two holes in the cover with the main alternator bracket ridge. (This is a small area and must be matched up properly.)
3. Mark holes in cover to ridge in bracket using a fine point marker or scribe.
4. Using a 9/64 drill bit, drill marked holes only about 1/4" deep.
5. Place cover back over drilled areas and place screws (provided) through plastic washers then tighten. **BE CAREFUL NOT TO OVER TIGHTEN.** Push chrome caps (provided) onto screws until they snap into place.