



AMERICAN CAR CRAFT INSTRUCTION

CORVETTE STAINLESS FUSE BOX COVER

PART # 033076 patent pending



PARTS INCLUDED:

1-Stainless Fuse Box Cover
1-2" Stainless Screw Cover w/Hook and Loop Fastener
1-Adhesive Promoter Pack
1-Hook and Loop Fastener Attachment Dot

1. Remove fuse relay cover.
2. Turn over the fuse relay cover and remove attachment screw by spreading the slits holding screw in place.
3. Slide off the positive battery post cover. This cover will not be reused.

NOTE: This is attached to the Fuse Relay Cover.

4. Place a few dabs of household silicone to both ends of the cover and place the cover over the Fuse Relay Cover.

5. Snap attachment screw back in and screw cover in place. You have been supplied with a round screw cover simply swipe the top of the attachment screw with the adhesive promoter provided and place the hook and loop fastener attachment dot directly to the screw head. Then you can attach the 2” stainless screw cover in place. NOTE: This cover will need to be removed to gain access to the attachment screw.

Thank you and enjoy your new purchase.

Note: Care must be taken when cleaning your cover. It is a good idea to lightly dust your cover with a clean soft cloth first in order to prevent any particles from scratching it. Then wipe (using a new clean soft cloth) with a good quality streak free glass cleaner.

AMERICAN CAR CRAFT