




## AMERICAN CAR CRAFT INSTRUCTIONS

---

***C5 Corvette Hood Panel Badge (1997-2004 Factory Hood Panel Only)***

***PART #033080***



**PARTS INCLUDED:**

- 1- C5 Emblem
- 1-Adhesive Promoter

**PROTECTIVE LINER INFORMATION:** Your new accessories will come to you with a protective surface liner. Leave this liner in place until the installation is complete to prevent finger prints and/or possible scratches during installation.

1. Remove the factory hood panel (pad) by popping all the hood retainers off. Keep these fasteners; they will be re-used to re-install the hood panel.
2. Wipe the indented C5 hood panel emblem with a cleaner to remove any kind of grease or dirt from the road.
3. Use the supplied adhesive promoter packet and wipe the indented C5 hood panel emblem.
4. Now the C5 emblem will have 7 tabs sticking out of the back of the part. (These tabs are very pointy so be careful while installing it so that you don't poke yourself) These tabs will push through the factory black hood pad and bend back onto the hood pad. Holding the emblem to the hood pad.

5. Pull the Red 3M tape backing off and stick the emblem to the hood pad while pushing the tabs through the factory hood pad. Be careful to align the emblem properly the first time. You will not be able to make adjustments. And bend the tabs flat onto the back of the factory hood pad.

**OPTIONAL STEP:** Use a large dab of silicone adhesive when re-installing the hood panel, between the hood panel and hood. This will secure the hood panel to the hood and keep it from any potential sagging.

6. Once the emblem has been completely installed on the hood panel, reinstall the hood panel with the factory fasteners.

**OPTIONAL ACCESSORY:** You may also like our Part #043112 Hood Pad Button Kit.

